BLADE™ 11 Prime

# User Guide

# About This Guide

Thank you for choosing this ZTE mobile device. In order to keep your device in its best condition, please read this manual and keep it for future reference.

## Copyright

**Copyright © 2021 ZTE CORPORATION**

**All rights reserved.**

No part of this publication may be quoted, reproduced, translated or used in any form or by any means, electronic or mechanical, including photocopying and microfilm, without the prior written permission of ZTE Corporation.

## Notice

ZTE Corporation reserves the right to make modifications on print errors or update specifications in this manual without prior notice. This manual has been designed with the utmost care to ensure the accuracy of its content. However, all statements, information and recommendations contained therein do not constitute a warranty of any kind, either expressed or implied. We offer self-service for our smart terminal device users. Please visit the ZTE official website (at www.zteusa.com) for more information on self-service and supported product models. Information on the website takes precedence.

## Disclaimer

ZTE Corporation expressly disclaims any liability for faults and damages caused by unauthorized modifications of the software.

Images and screenshots used in this manual may differ from the actual product. Content in this manual may differ from the actual product or software.

## Trademarks

ZTE, Blade, and the ZTE logos are trademarks of ZTE Corporation.

LTE is a trademark of ETSI.

Android™ is a trademark of Google LLC.

The *Bluetooth*® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by ZTE Corporation is under license.

microSDXC Logo is a trademark of SD-3C, LLC.

Other trademarks and trade names are those of their respective owners.

**Version No.:** R1.0

**Edition Time:** April 9, 2021

# Contents


**Getting Started ..... 10**

Getting to Know Your Phone ..... 10
Key Functions ..... 12
Installing a nano-SIM Card and an Optional microSDXC Card ... 13
Charging the Battery ..... 15
Powering Your Phone On/Off ..... 17
Setting Up Your Phone for the First Time ..... 17
Locking/Unlocking the Screen and Keys ..... 17
Getting to Know the Home Screen ..... 19

**Personalizing ..... 21**

Changing the System Language ..... 21
Setting the Date and Time ..... 21
Changing the Ringtone or Notification Sound ..... 22
Turning System Sounds On/Off ..... 23
Adjusting Volumes ..... 23
Switching to Silent or Vibration Mode ..... 23
Using Do Not Disturb Mode ..... 24
Applying New Wallpapers ..... 25
Setting the Home Screen Options ..... 26
Using Night Light ..... 26
Using Dark Theme ..... 27
Protecting Your Phone With a Screen Lock ..... 27
Protecting Your Phone With App Pinning ..... 28

Using Your Fingerprint....30
Using Face Recognition....31

**Knowing the Basics....34**

Monitoring the Phone Status....34
Managing Notifications....35
Managing Shortcuts and Widgets....38
Organizing With Folders....38
Rearranging the Primary Shortcuts....39
Using App Shortcuts....39
Notification Dots (App Badges)....40
Editing Text....41
Opening and Switching Apps....42
Using Two Apps in Split-Screen Mode....43
Uninstalling an Application....43
Using One-Handed Mode....43

**Connecting to Networks and Devices....45**

Connecting to Mobile Networks....45
Connecting to Wi-Fi....46
Connecting to *Bluetooth* Devices....49
Sharing Files With Nearby Devices....51
Connecting to Your Computer via USB....54
Using the microSDXC Card as Portable or Device Storage....55
Sharing Mobile Data Through Tethering....58

**Phone Calls ..... 60**
Placing and Ending Voice Calls ..... 60
Answering or Rejecting Voice Calls ..... 61
Using Real-Time Text (RTT) ..... 62
Working With the Call History ..... 64
Calling Your Contacts ..... 66
Checking Voicemail ..... 66
Using Options During a Call ..... 67
Managing Multi-party Calls ..... 68
Adjusting Your Call Settings ..... 70

**Contacts ..... 75**
Checking Contact Details ..... 75
Adding a New Contact ..... 75
Importing, Exporting, and Sharing Contacts ..... 76
Working With Favorite Contacts ..... 77
Managing Contacts With Labels ..... 78
Managing Emergency Contacts and Information ..... 79
Searching for a Contact ..... 81
Editing Contacts ..... 81

**Web Accounts ..... 84**
Adding or Removing Accounts ..... 84
Configuring Account Sync ..... 85

**Email ..... 87**
Setting Up the First Email Account ..... 87

Checking Your Emails ..... 87
Responding to an Email ..... 88
Writing and Sending an Email ..... 89
Managing Email Accounts ..... 90
Changing General Email Settings ..... 91

**Messages ..... 92**
Opening the Messages Screen ..... 92
Sending a Message ..... 92
Replying to a Message ..... 94
Forwarding a Message ..... 94
Deleting Messages or Conversations ..... 95

**Web Browser ..... 96**
Opening the Browser ..... 96
Using Multiple Browser Tabs ..... 96
Downloading Files ..... 97

**Camera ..... 98**
Capturing a Photo ..... 98
Recording a Video ..... 100
Using Manual Camera Mode ..... 101
Using Portrait Mode ..... 102
Using Panorama Mode ..... 102
Using Other Camera Modes ..... 103
Customizing Camera and Video Settings ..... 103

**FM Radio ..... 107**
Scanning and Saving Channels..... 107
Listening to FM Radio..... 107
Other Options and Settings ..... 108

**Voice Recorder..... 109**
Recording a Voice Memo..... 109
Playing a Voice Memo ..... 110
Trimming a Voice Memo..... 110

**More Apps.....111**
Calculator..... 111
Clock..... 111
File Manager ..... 113
Weather ..... 114
Google Apps ..... 114

**Settings ..... 116**
Network & Internet..... 116
Connected Devices ..... 118
Apps & Notifications ..... 119
Battery..... 121
Features..... 121
Display ..... 122
Sound..... 122
Storage..... 123
Privacy..... 123

Location ..... 124
Security ..... 124
Accounts ..... 126
Accessibility ..... 126
Digital Wellbeing & Parental Controls ..... 127
Google ..... 128
System ..... 128
About Phone ..... 130
System Updates ..... 131

**Upgrading the Phone Software ..... 132**

**Troubleshooting ..... 133**

**For Your Safety ..... 138**

General Safety ..... 138
Radio Frequency (RF) Energy ..... 139
FCC Regulations ..... 141
Hearing Aid Compatibility (HAC) Regulations for Mobile Phones ..... 142
Distractions ..... 144
Product Handling ..... 145
Electrical Safety ..... 150
Radio Frequency Interference ..... 151
Explosive Environments ..... 152

# Getting Started

## Getting to Know Your Phone




Headset jack
Auxiliary microphone
Back cameras
Flash
Charging/USB Type-C jack

# Key Functions

| Key | Function |
|---|---|
| Power key | • Press and hold to power on, restart the phone, or power off.<br>• Press to turn on/off the display. |
| Volume key | Press or hold either end of the key to turn the volume up or down. |
| (Home key) | • Touch to return to the home screen from any application or screen.<br>• Touch and hold to use the Google Assistant. |
| (Recent apps key) | • Touch to see recently used applications.<br>• Touch twice to switch between the two most recent applications. |
| (Back key) | Touch to go to the previous screen. |

**NOTE:**

You can replace the **Home** key, the **Recent apps** key, and the **Back** key with another navigation style. Swipe up on the home screen and touch **Settings > Features > System navigation** to select navigation bar styles, see tutorials, and personalize settings.

# Installing a nano-SIM Card and an Optional microSDXC Card

The nano-SIM card can be installed or removed while the phone is turned on.

**WARNING!**

To avoid damage to the phone, do not use any other kind of SIM cards, or any non-standard nano-SIM card cut from a SIM card. You can get a standard nano-SIM card from your service provider.

1. Insert the tip of the tray eject tool into the hole on the card tray on the left side of the phone.



**NOTE:**

Please use the tray eject tool included in the box. Otherwise the card tray may not be ejected.

**CAUTION:**

Never replace the included tray eject tool with other sharp objects. Ensure that the tray eject tool is perpendicular to the hole. Otherwise, the phone may be damaged.

2. Pull out the card tray and place a nano-SIM card and an optional microSDXC card on the respective slots on the card tray, as shown. Note the notch and shape of the cards and the card slots.



**NOTE:**

Some applications may require a microSDXC card to work normally and/or may store data on the card. Therefore, it is recommended that you keep a microSDXC card installed and not remove or replace it randomly.

3. Carefully slide the tray back into place.

# Charging the Battery

Your phone's battery should have enough power for the phone to turn on, find a signal, and make a few calls. You should fully charge the battery as soon as possible.

**WARNING!**

Use only ZTE-approved chargers and USB Type-C cables. The use of unapproved accessories could damage your phone or cause the battery to explode.

**WARNING!**

**Do not remove the back cover. The battery is not removable. Removal may cause fire or explosion.**

1. Connect the adapter to the charging jack.



2. Connect the charger to a standard AC power outlet. If the phone is on, you'll see a charging icon, such as or , appear in the status bar.
3. Disconnect the charger when the battery is fully charged.

**NOTE:**

If the battery is extremely low, you may be unable to power on the phone even when it is being charged. In this case, try again after charging the phone for at least 20 minutes. Contact customer service if you still cannot power on the phone after prolonged charging.

# Powering Your Phone On/Off

- Press and hold the **Power** key to turn on your phone.
- To turn it off, press and hold the **Power** key to open the options menu and touch > .

**NOTE:**

If the screen freezes or takes too long to respond, try pressing and holding the **Power** key for over 10 seconds to restart the phone.

# Setting Up Your Phone for the First Time

When you first power on your phone after you purchase it or reset it to factory settings (see *Reset Options*), you will need to set it up before using it. Select the language and then follow the prompts to set up your phone.

# Locking/Unlocking the Screen and Keys

Your phone allows you to quickly lock the screen and keys (put the phone to Sleep mode) when not in use and also to turn the screen back on and unlock it when you need it.

## Lock the Screen and Keys

To quickly turn the screen off and lock the keys, press the **Power** key.

**NOTE:**

To save battery power, the phone automatically turns off the screen after a certain period of time when you leave it idle. You will still be

able to receive messages and calls while the phone screen is off.

## Unlock the Screen and Keys

1. Press the **Power** key to turn the screen on.
2. Swipe up on the screen.

   - or -

   Swipe away from at the bottom right of the screen to open the Camera app.

   - or -

   Double-tap a notification to open the related app.

**NOTE:**

If you have set a pattern, a PIN, or a password as the screen lock or registered your fingerprint or face, you'll need to unlock the screen by drawing the pattern, entering the PIN/password, touching the fingerprint sensor, or showing your face to the front camera. See *Protecting Your Phone With a Screen Lock*, *Using Your Fingerprint*, and *Using Face Recognition*.

# Getting to Know the Home Screen

The home screen is the starting point for your phone's applications, functions, and menus. You can customize your home screen by adding shortcuts, folders, widgets, and more.

## Extended Home Screen Panels

Your home screen is extendable, providing more space for shortcuts, widgets, and more. Add a few extended home screen panels and you can swipe left or right to switch between panels. You can also remove some panels.

**NOTE:**

Swipe right on the left-most panel to use the Google app.

***To add a new home screen panel:***

Touch and hold a shortcut, a folder, or a widget and drag it to the right edge of the home screen. A new panel is created automatically and you can release the item on the new panel.

**NOTE:**

Touch and hold an empty area of the home screen and then touch at the top of a home screen panel to set it as the main home screen.

***To delete a home screen panel:***

Remove all shortcuts, folders, and widgets from a panel (see *Remove Shortcuts or Widgets*) and the panel is deleted automatically.

# Personalizing

## Changing the System Language

1. Swipe up on the home screen and touch **Settings** > **System** > **Languages & input** > **Languages**.
2. Touch **Add a language** to add another language to the list.
3. To change the system language, touch and hold the language you need and drag it to the top of the list.

**NOTE:**

To remove languages from the list, touch > **Remove**, select the languages you want to delete, and touch > **REMOVE**.

## Setting the Date and Time

1. Swipe up on the home screen and touch **Settings** > **System** > **Date & time**.
2. Set the date, time, time zone, and time format.
   - To adjust the date and time automatically, touch to turn on **Use network-provided time**.
   - To adjust the date and time manually, touch to turn off **Use network-provided time** and touch **Date**/**Time** to change the date and time.
   - To adjust the time zone automatically, touch to turn on **Use network-provided time zone**.

- To adjust the time zone manually, touch to turn off **Use network-provided time zone** and touch **Time zone** to set the correct time zone.
- To adjust the time format, touch to turn on **Use locale default** or turn off this option and switch on/off **Use 24-hour format**.

# Changing the Ringtone or Notification Sound

You can customize the default ringtone for incoming calls or the default notification sound.

1. Swipe up on the home screen and touch **Settings > Sound > Advanced > Ringtones**.
2. Touch **Phone ringtone** or **Default notification sound**.
3. Scroll through the list and select the ringtone you'd like to use.
4. Touch **OK**.

**NOTES:**

- Many applications have their own notification sound settings.
- See *Set a Ringtone for a Contact* for how to assign a special ringtone to an individual contact.
- When selecting ringtones or sounds, touch **Add ringtone / Add notification** to select an audio file on your phone or microSDXC card.

# Turning System Sounds On/Off

1. Swipe up on the home screen and touch **Settings** > **Sound** > **Advanced**.
2. In the **OTHER SOUNDS AND VIBRATIONS** section, touch the switches beside each option to turn it on or off.

# Adjusting Volumes

1. Swipe up on the home screen and touch **Settings** > **Sound**.
2. Drag the sliders below **Media volume**, **Ring volume**, **Alarm volume**, **Notification volume**, and **Call volume** to adjust the volume for each type of audio.

**NOTE:**

You can adjust the media volume by pressing the **Volume** key. During a call, press the key to adjust the call volume.

# Switching to Silent or Vibration Mode

You can set the phone to silent or vibration mode by using one of the following methods.

**NOTE:**

Silent and vibration modes will not silence your alarms.

- Press the **Volume** key and touch or to switch the phone to vibration or silent mode.

- Swipe up on the home screen and touch **Settings** > **Sound** > **Advanced** > **Notification mode** and select **Vibrate** or **Mute** to switch to vibration or silent mode.
- Swipe down from the top of the screen to open the notification panel and drag the panel downwards. Touch **Ring** or **Vibrate** to switch the phone to vibration or silent mode. See *Use Quick Settings*.

**NOTE:**

To restore normal sound settings, press the **Volume** key and touch , select **Ring** in the Notification mode menu, or open the Quick Settings panel and touch **Silent**.

# Using Do Not Disturb Mode

You can limit interruptions with Do Not Disturb mode. This mode silences your phone so that it doesn't make sounds, vibrate, or show notifications when you don't want it to.

## Turn on Do Not Disturb Mode

1. Swipe down from the top of the screen with two fingers to access the Quick Settings panel.
2. Swipe left and right to find the "Do Not Disturb" icon and touch it.

## Set Do Not Disturb Mode

1. Swipe up on the home screen and touch **Settings** > **Sound** > **Do Not Disturb**.

2. Touch the following options as you need (Touch **Advanced** to see all options).
   - **People:** Allow selected types of calls, messages, or conversations to interrupt.
   - **Apps:** Choose which apps can send you notifications in Do Not Disturb mode.
   - **Alarms & other interruptions:** Allow alarms, media sounds, touch sounds, reminders, or calendar events to interrupt.
   - **Schedules:** Use schedules to turn on/off Do Not Disturb mode automatically. Touch an existing schedule to use it, or touch next to a schedule to edit or delete it. You can also touch **Add more** to create new schedules.
   - **Duration for Quick Settings:** Set how long Do Not Disturb mode will stay on when you turn it on.
   - **Display options for hidden notifications:** Set notification behavior in Do Not Disturb mode. You can block sound or visuals from notifications, or customize more restrictions.

# Applying New Wallpapers

You can set the wallpaper for the home screen and lock screen.

1. Touch and hold an empty place on the home screen and select **Wallpaper**.

   – or –

   Swipe up on the home screen and touch **Settings** > **Display** > **Wallpaper**.

2. Touch a wallpaper thumbnail or **GALLERY** and choose an image. For gallery images, you can pan and zoom to select the area of the image you want to use.
3. Touch **SET AS** and choose where the wallpaper should be used by touching **Set Home screen**, **Set lock screen**, or **Set both**.

## Setting the Home Screen Options

1. Touch and hold an empty place on the home screen.
2. Touch **Effect** to choose a transition effect between home screen panels.

   To set other options, touch **Settings** to customize options including adding new app icon, app badges, icon layout, home screen mode, screen looping, layout lock, app auto-fill, and Google app display.

## Using Night Light

You can enable Night Light to tint the screen amber to reduce eye strain.

1. Swipe up on the home screen and touch **Settings** > **Display** > **Night Light**.
2. Touch **TURN ON NOW** and adjust the intensity bar to a comfortable level.

**NOTE:**

If you want the phone to turn on/off Night Light automatically, touch **Schedule** to set the start and end time.

# Using Dark Theme

When the Dark theme is enabled, your phone will turn the screen to dark with white text on a black background, relieving eye irritation caused by screen glare at night.

1. Swipe up on the home screen and touch **Settings** > **Display** > **Dark theme**.
2. Switch on **TURN ON NOW** to enable Dark theme.

   – or –

3. If you want the Dark theme turned on and off automatically, touch **Schedule** to enable automatic Dark theme and set a schedule.

**NOTE:**

Not all apps support the Dark theme.

# Protecting Your Phone With a Screen Lock

You can protect your phone by creating a screen lock. When it is enabled, you can swipe up on the lock screen, and then draw a pattern or enter a numeric PIN or password to unlock the phone's screen and keys.

1. Swipe up on the home screen and touch **Settings** > **Security** > **Screen lock**.
2. Touch **None**, **Swipe**, **Pattern**, **PIN**, or **Password**.
   - Touch **None** to disable screen lock protection.
   - Touch **Swipe** to enable screen lock and allow unlocking with

a “swipe” gesture. You can unlock the screen by touching the display and sliding up.

- Touch **Pattern** to create a pattern that you must draw to unlock the screen.
- Touch **PIN** or **Password** to set a numeric PIN or a password that you must enter to unlock the screen.

3. For Pattern, PIN, or Password, select how you want notifications and their contents to show when the phone is locked, and then touch **Done**.

**NOTE:**

Remember the pattern, PIN, or password you set. Otherwise, you will have to upgrade the phone software to use the phone (see *Upgrading the Phone Software*).

# Protecting Your Phone With App Pinning

You can pin an app's screen to keep it in view until you unpin it. This feature can be used, for example, to let a trusted friend play a specific game.

**NOTE:**

When an app is pinned, the pinned app may open other apps and your personal data may be accessible.

## Turn On App Pinning

1. Swipe up on the home screen and touch **Settings** > **Security** > **Advanced** > **App pinning**.
2. Touch the **On/Off** switch.

3. Read the on-screen prompt and touch **OK**.
4. To automatically lock the phone after unpinning, switch on **Lock device when unpinning** and set up a screen lock.

   If you have set a screen lock, you can switch on **Ask for unlock pattern before unpinning**, **Ask for PIN before unpinning**, or **Ask for password before unpinning** if you've set a screen lock already.

## Pin an App

1. Ensure that app pinning is turned on.
2. Open the app you want to keep in view.
3. Touch the **Recent apps** key.
4. Touch ⋮ above the app thumbnail and select **Pin**.

## Unpin the App

1. To unpin the app and return to normal use, touch and hold both the **Back** key and the **Recent apps** key.

   **NOTE:**

   For Gesture navigation, swipe up from the bottom of the screen and hold for a while to unpin.
2. If the screen is locked, swipe up on the lock screen and draw the pattern or enter the PIN/password you set.

   If you have registered fingerprints or face data, you can also unlock with your finger or face.

# Using Your Fingerprint

## Register a Fingerprint

1. Swipe up on the home screen and touch **Settings** > **Security** > **Fingerprint** > **Fingerprint management**.
2. If you have not set a screen lock, choose one backup screen lock method to set the screen lock pattern, PIN, or password. If you have already set a screen lock, draw the pattern or enter the PIN/password.
3. Touch **REGISTER** or **Add fingerprint**.
4. Follow the prompts to record the center and the edges of a finger.
5. Touch **OK** when your fingerprint has been registered.

**NOTE:**

Registered fingerprints are listed in the Fingerprint management menu. You can register up to 5 fingerprints. Touch an existing fingerprint record to change its name or delete it.

## Manage the Fingerprint Function

You can use registered fingerprints to unlock the phone or disable this function.

1. Swipe up on the home screen and touch **Settings** > **Security** > **Fingerprint** > **Fingerprint management**.
2. Enter the screen lock pattern, PIN or password you set.

3. Touch **Wake up and unlock your phone** to allow or forbid unlocking the phone with fingerprints.

# Using Face Recognition

You can use face recognition to unlock the screen.

**NOTES:**

- The security strength of face recognition is lower than that of password, pattern and fingerprint. To improve the security of your phone while you have registered your face, high security level is enabled by default, which requires you to enter the security password (the Pattern, PIN, or Password you set for screen lock) at least once every 24 hours. You can change the security level in the face recognition menu.
- If you restart your phone, you need to enter the screen lock pattern, PIN or password you set to unlock the screen for the first time.

## Register Your Face

1. Swipe up on the home screen and touch **Settings** > **Security** > **Face recognition**.
2. Enter the screen lock pattern, PIN or password you set. If you have not set a screen lock, choose one backup screen lock method to set the screen lock pattern, PIN or password.
3. Read the disclaimer for face recognition and touch **ACCEPT**.
4. Touch **CREATE NOW** and follow the prompts to register your face.

## Use Face Recognition to Unlock the Screen

After registering your face, you can unlock the screen with face recognition.

1. Press the **Power** key to turn on the screen display if the screen is off.
2. Put your face in front of the screen. If the face recognition fails, touch to try again.
3. Depending on your setting, you may need to swipe up on the screen to unlock the phone.

## Set Face Recognition Options

You can set what face recognition can do on your phone.

1. Swipe up on the home screen and touch **Settings > Security > Face recognition**.
2. Enter the screen lock pattern, PIN or password you set.
3. You can set the following options.
   - **Unlock phone:** Set whether you need to swipe up on the screen to unlock the phone after your face is recognized.
   - **Do not recognize face when eyes are closed:** Set whether to unlock the phone by face recognition when your eyes are closed.
   - **Screen brightness compensation:** If this option is enabled, the phone will increase screen brightness automatically in a dim light to help verify your face.

- **Delete facial data:** Delete your recorded face data.
- **Security settings:** Set the security level of your phone while face recognition is enabled.

# Knowing the Basics

## Monitoring the Phone Status

The status bar at the top of the home screen provides phone and service status icons on the right side. Below are some of the icons you may see.

| Indicator | What it means |
|---|---|
| | 4G LTE connected |
| | Do not disturb mode on |
| | Vibration only mode on |
| | Silent mode on |
| | Battery low |
| | Battery full |
| | Battery charging |
| | Alarm set |
| | Data Saver on |
| | No signal |
| | Signal strength |
| | Airplane mode |
| | Connected to a Wi-Fi network |

| | |
|---|---|
| | Speaker on |
| | Phone microphone off |
| | Location service active |
| | Wired headset connected |

# Managing Notifications

The status bar at the top of the home screen provides notification icons on the left. Below are some of the icons you may see.

| Indicator | What it means |
|---|---|
| | New message |
| | New message(s) from the Gmail™ app |
| | New message(s) from the Email app |
| | Missed call |
| | Call in progress |
| | Upcoming event |
| | New Wi-Fi network detected |
| | Downloading/sending data |

## Open/Close the Notification Panel

Notifications report the arrival of new messages, calendar events, and alarms, as well as ongoing events. You can open the notification panel to view the details of notifications.

- To open the notification panel, swipe your finger down on the home screen or from the top of the screen.
- To close the notification panel, swipe your finger up on the screen or touch the **Back** key.

## Respond to or Remove a Notification

In the notification panel, you can respond to a notification or remove the notifications. The notification panel also supports expandable notifications that let you perform additional actions right from the notification itself.

- To respond to a notification, touch it.
- Slide down with one finger to expand certain notifications. You can also touch ⌄/⌃ to expand or collapse them.
- To remove a notification, swipe it left or right.
- To remove all nonpersistent notifications, touch **Clear all** below all the notifications.
- To manage notifications you have received, touch and hold a notification, or slide it left or right a little and touch ⚙, and then choose to turn off or silence this type of notification. Or touch ⚙ again to customize more notification settings for the app. See *Apps & Notifications*.

**NOTE:**

If you turn off notifications for an app, you may miss its important alerts and updates. Some notifications (such as those from the system) cannot be turned off.

# Use Quick Settings

The Quick Settings make it convenient to view or change the most common settings for your phone.

Open the notification panel and you can find a few Quick Settings on the top. To open the Quick Settings panel and find all setting tiles, drag the notification panel downwards, or swipe down from the top of the screen with two fingers.

**NOTE:**

You can swipe left or right on the Quick Settings panel to find all setting tiles.

***To turn on or off settings quickly:***

From the Quick Settings panel, touch a tile to turn its feature on or off.

Touch and hold certain tiles to access more setting options. For example, touch and hold the Wi-Fi tile to open Wi-Fi settings.

***To customize the Quick Settings panel:***

You can add, remove or rearrange the tiles on the Quick Settings panel.

Touch below the panel and do one of the following:

- Touch and hold a tile and drag it to the position you want.
- Touch and hold a tile and drag it to the section below “DRAG HERE TO REMOVE” to hide it.
- In the “HOLD AND DRAG TO ADD TILES” section, drag a tile up to show it in the Quick Settings panel.

# Managing Shortcuts and Widgets

## Add Shortcuts and Widgets

1. To add a shortcut, swipe up on the home screen.

   To add a widget, touch and hold an empty area of the home screen and select **Add a widget**.
2. Slide to browse the available applications or widgets.
3. Touch and hold a widget or an application icon and drag it to a home screen panel.

**NOTE:**

While holding the shortcut or widget, you can drag it to the right edge of the screen to create a new home screen panel and put the item on it.

## Move Shortcuts or Widgets

1. Touch and hold a shortcut or widget on the home screen.
2. Drag it to the place you need.

## Remove Shortcuts or Widgets

1. Touch and hold a shortcut or widget on the home screen.
2. Touch **Delete** to remove it.

# Organizing With Folders

You can create folders on the home screen and add several shortcuts to a folder.

You can move or remove folders the same way as moving or removing shortcuts.

1. On the home screen, touch and hold the shortcut you want to add into a new folder.
2. Drag the shortcut over another and release. A new folder is created and both shortcuts are added into the folder.
3. To add more shortcuts into the folder, touch and hold each shortcut and drag it over the folder before releasing it.

**NOTES:**

- To remove a shortcut from a folder, touch the folder to open it. Touch and hold the shortcut and drag it to the home screen.
- Touch the folder and then touch the name field above the shortcut icons to rename the folder.

## Rearranging the Primary Shortcuts

The home screen includes a customizable primary shortcuts area at the bottom of all home screens. You can keep up to five items in the primary shortcuts area. Drag shortcuts or folders in or out of the area to rearrange them.

## Using App Shortcuts

The app shortcuts feature allows you to quickly access typical app functions from the home screen and the app list screen.

**NOTE:**

Not all apps support the app shortcuts feature.

1. Touch and hold an app icon on the home screen or the app list.
2. From the displayed options, touch the function you want to use.




**NOTE:**

You can touch and hold next to an option and drag it to the home screen to create a shortcut.

# Notification Dots (App Badges)

Some apps can display a dot or a number to indicate that they have new or unhandled notifications. The indications appear on the app icons on both the home screen and the app list screen.

Touch and hold an app icon with a notification dot to preview its new notifications without going to the notification panel.



***To show the app badge as dot or number:***

Touch and hold an empty area of the home screen and touch **Settings > Home screen badge app icon > Show badge as**.

***To turn on/off notification dots for all apps:***

Touch and hold an empty area of the home screen and touch **Settings > Home screen badge app icon > On/Off**.

***To turn on/off notification dots for specific apps:***

1. Swipe up on the home screen and touch **Settings > Apps & notifications > Notifications > Advanced**.
2. Switch on **Notification dot on app icon**.
3. Touch the **Back** key **> SEE ALL [number] APPS**.
4. Touch the app you want to customize and touch **Notifications > Advanced > Allow notification dot**.

# Editing Text

- **Move the insertion point:** Touch where you want to type. The cursor blinks in the new position, and a tab appears below it. Drag the tab to move the cursor.
- **Select text:** Touch and hold or double-tap within the text. The nearest word highlights, with a tab at each end of the selection. Drag the tabs to change the selection. Touch **Select all** or ⋮ **> Select all** to select all the text.
- **Cut or copy:** Select the text you want to manipulate. Then touch **Cut** or **Copy** to cut or copy the text to the clipboard.
- **Replace text with the clipboard text:** Select the text you want to replace. Then touch **Paste**.
- **Insert clipboard text in the text field:** Touch the tab below the cursor. Then touch **Paste**.

# Opening and Switching Apps

## Open an App

1. Swipe up on the home screen
2. Swipe up or down on the screen and touch an app to open it.

**NOTES:**

- Drag the index list on the right side of the screen to the initial letter of the app you need, or touch the search box at the top to search for apps.
- Touch ⋮ in the search box to sort the apps alphabetically, by the time they are installed, or by frequency of use.
- Some apps offer shortcuts to certain features. Touch and hold the app icon to get the shortcuts. You can also drag them to the home screen as shortcut icons. See *Using App Shortcuts*.

## Switch Between Recently Opened Apps

1. Touch the **Recent apps** key. The apps you've used recently are displayed as a series of cards. Slide left and right to see all the cards.
2. Touch a card to open that app.

**NOTES:**

- You can swipe a card up to remove it from the screen, which will free up running memory on the phone. Touch ⊗ to remove all cards.
- Touch the **Recent apps** key twice to switch to the most recent app you used.

# Using Two Apps in Split-Screen Mode

You can work with two apps at the same time in split-screen mode.

**NOTE:**

Some apps may not support split-screen mode.

1. Open the first app you want to use and touch the **Recent apps** key.
2. Touch above the app thumbnail. The app will attach to the upper part of the screen.
3. Open the second app from the recent app cards or the app list.

Drag the middle of the border between the two apps to adjust their size. Drag the border to the top or bottom of the screen to exit split-screen mode. The expanding app will be kept in full screen.

# Uninstalling an Application

1. Touch and hold an application icon on the home screen or in the app list to display available options.
2. Touch **Uninstall** > **OK** to uninstall the app.

**NOTE:**

Some preinstalled apps cannot be uninstalled.

# Using One-Handed Mode

You can enable one-handed mode to comfortably operate your phone with one hand.

1. Open **Settings**, touch **Features** > **One-handed mode** and turn on the switch.

**NOTE:**

The One-handed mode option is not available when gesture navigation is enabled.

2. Touch and hold the **Back** key to enter one-handed mode. You can do the following.
   - Touch or to move the small screen to the right or left.
   - Drag or at the top corner of the small screen to resize the screen.
   - Touch the empty area outside the small screen to exit one-handed mode.

# Connecting to Networks and Devices

## Connecting to Mobile Networks

### Control Mobile Data Use

***To enable or disable mobile data:***

1. Swipe up on the home screen and touch **Settings > Network & internet > Mobile network**.
2. Touch the **Mobile data** switch to enable or disable mobile data use.

***To get data services while roaming:***

1. Swipe up on the home screen and touch **Settings > Network & internet > Mobile network**.
2. Touch **roaming** to enable or disable international data roaming.

**NOTE:**

Data roaming may incur significant roaming charges.

### Add Access Point Names

To connect to the Internet you can use the default Access Point Names (APNs).

1. Swipe up on the home screen and touch **Settings > Network & internet > Mobile network > Advanced > Access Point Names**.
2. Touch +.

3. Touch each field to enter the required information. Contact your mobile service provider for details.
4. Touch ⋮ > **Save**.

**NOTE:**

To set the APN to default settings, touch ⋮ > **Reset to default**.

## Select Network Operator

1. Swipe up on the home screen and touch **Settings** > **Network & internet** > **Mobile network** > **Advanced**.
2. Touch to turn off **Automatically select network**.
3. Wait for the phone to search for available networks and touch a network in the network list to register manually.

# Connecting to Wi-Fi

Wi-Fi is a wireless networking technology that can provide Internet access at distances of up to 300 feet (100 meters), depending on the Wi-Fi router and your surroundings.

## Turn Wi-Fi On and Connect to a Wi-Fi Network

1. Swipe up on the home screen and touch **Settings** > **Network & internet** > **Wi-Fi**.
2. Slide the **Use Wi-Fi** switch to the on position to turn on Wi-Fi. Your phone will search for available networks.
3. Touch a network name to connect to it.
4. If the network is secured, enter the password and touch **CONNECT**.

**NOTES:**

- Your phone automatically connects to previously used Wi-Fi networks when they are in range.
- If you have a QR code for the Wi-Fi network, touch below the list of available networks and scan the QR code to connect.

## Get Notified of Good Public Networks

1. Swipe up on the home screen and touch **Settings** > **Network & internet** > **Wi-Fi** > **Wi-Fi preferences**.
2. Slide the **Notify for public networks** switch to the **On** position.

When Wi-Fi is on, you receive notifications in the status bar when your phone detects a high-quality public Wi-Fi network. Switch off this option to turn off notifications.

## Add a Wi-Fi Network

You can add a Wi-Fi network if the network does not broadcast its name (SSID) or when you are out of range.

To connect to a secured network, you first need to get the security details from the network's administrator.

1. Swipe up on the home screen and touch **Settings** > **Network & internet** > **Wi-Fi**.
2. Slide the **Use Wi-Fi** switch to the **On** position.
3. At the bottom of the available networks, touch **Add network**.
4. Enter the network SSID (name). If necessary, enter security or other network configuration details.

5. Touch **SAVE**.

## Forget a Wi-Fi Network

You can make your phone forget the details of a Wi-Fi network that you added—for example, if you don't want the phone to connect to it automatically or if the network is no longer useful.

1. Swipe up on the home screen and touch **Settings > Network & internet > Wi-Fi**.
2. Touch **Saved networks**.
3. Touch the Wi-Fi network name and then touch **FORGET**.

## Adjust Other Wi-Fi Settings

1. Swipe up on the home screen and touch **Settings > Network & internet > Wi-Fi > Wi-Fi preferences**.
2. Adjust the following settings as you need.
   - **Turn on Wi-Fi automatically:** Allow the phone to turn Wi-Fi on near high-quality saved networks, like your home network.
   - **Notify for public networks:** Turn on/off notification for available high-quality public Wi-Fi network.
   - **Avoid bad Wi-Fi connections:** Automatically switch to mobile data when the Wi-Fi you are using has no Internet connection.
   - **Install certificates:** Install certificates needed for connecting to certain Wi-Fi networks.
   - **Network rating provider:** Select the rating provider for Wi-Fi network quality.

# Connecting to *Bluetooth* Devices

*Bluetooth* is a short-range wireless communication technology. Phones or other devices with *Bluetooth* capabilities can exchange information wirelessly within a few feet. The *Bluetooth* devices must be paired before the communication is performed.

## Change the Device Name

1. Swipe up on the home screen and touch **Settings** > **Connected devices** > **Connection preferences** > **Bluetooth**.
2. Slide the **Bluetooth** switch to the **On** position if *Bluetooth* is off.
3. Touch **Device name**.
4. Edit the name and touch **OK**.

## Pair With Another *Bluetooth* Device

1. Swipe up on the home screen and touch **Settings** > **Connected devices** > **Pair new device**.

   Your phone automatically turns *Bluetooth* on and scans for and displays the IDs of all available *Bluetooth* devices in range.
2. Touch the device you want to pair with.
3. If necessary, confirm that the *Bluetooth* passkeys are the same between the two devices and touch **PAIR**. Alternatively, enter a *Bluetooth* passkey and touch **PAIR**.

   Pairing is successfully completed when the other device accepts the connection or the same passkey is entered.

**NOTE:**

The *Bluetooth* passkey may be fixed for certain devices, such as headsets and hands-free car kits. You can try entering 0000 or 1234 (the most common passkeys) or refer to the documents for that device.

## Forget a *Bluetooth* Device

You can make your phone forget its pairing connection with another *Bluetooth* device. To connect to the device again, you need to search for it and enter or confirm a passkey again.

1. Turn *Bluetooth* on.
2. Swipe up on the home screen and touch **Settings > Connected devices**.
3. In the list of paired devices, touch beside the *Bluetooth* device you want to forget.
4. Touch **FORGET > FORGET DEVICE**.

## Send Data via *Bluetooth*

1. Open the appropriate application and select the file or item you want to share.
2. Select the option for sharing via *Bluetooth*. The method may vary by application and data type.
3. Touch a *Bluetooth* device the phone has paired with or wait for it to search for new devices and touch one of them.

## Receive Data via *Bluetooth*

1. Turn *Bluetooth* on before trying to receive data via *Bluetooth*.
2. When you see a notification at the top of the screen, touch **ACCEPT** to start receiving data. If necessary, swipe down on the status bar, and touch **ACCEPT** on the *Bluetooth* sharing notification.

Depending on your storage setting and whether a microSDXC card is installed, received files are stored automatically in a dedicated folder (*bluetooth*, for instance). You can access them with the File Manager app.

# Sharing Files With Nearby Devices

With Nearby Share, you can share photos, videos, and documents with nearby devices via Bluetooth or Wi-Fi.

## Turn Sharing On or Off

1. On your phone, make sure *Bluetooth*, Wi-Fi, and Location are turned on. See *Connecting to Bluetooth Devices*, *Connecting to Wi-Fi* and *Location*.
2. Swipe up on the home screen and touch **Settings > Connected devices > Connection preferences > Nearby Share**.
3. Touch **Turn on** or the switch at the top to turn Nearby Share on or off.

## Share Content With Someone

1. Open the content, like a photo or webpage on your phone.
2. Find and touch the Share option and then select Nearby Share.
3. Touch **Turn on** if Nearby Share is switched off.
4. Hold your phone and your friend's device which supports the Nearby Share feature close to each other.

   **NOTE:**

   Make sure both devices are unlocked, and have Nearby Share, Wi-Fi, Bluetooth and location turned on.
5. If prompted, touch the Nearby Share notification on your friend's device to make that device visible to nearby devices.
6. On your phone, your friend's device name will appear and touch the device name to send the content.
7. Accept the sharing on your friend's device.

## Get Content From Someone

1. Ask your friend to follow the "*Share Content With Someone*" steps above.
2. You'll get a notification that someone is sharing content with you. Touch the notification if you haven't set your phone visible to nearby devices.

   **NOTE:**

   Make sure both devices are unlocked, and have Nearby Share, Wi-Fi, Bluetooth and location turned on.
3. Touch **Accept** to get the content.

## Choose Who Can Share Content With You

1. Swipe up on the home screen and touch **Settings** > **Connected devices** > **Connection preferences** > **Nearby Share**.
2. Touch **Device visibility** and choose one of the following options.
   - **All Contacts:** Your phone is visible to your contacts while your phone screen is on and unlocked. You need to sign in to your Google account first.
   - **Some Contacts:** Your phone is visible to nearby contacts you choose while your phone screen is on and unlocked. You need to sign in to your Google account first.
   - **Hidden:** When you get a notification that someone is sharing content, you can choose to make your phone visible manually in order for that device to find your phone.

## Set Data Usage for Sharing

1. Swipe up on the home screen and touch **Settings** > **Connected devices** > **Connection preferences** > **Nearby Share**.
2. Touch **Data** and choose one of the following options.
   - **Data:** Mobile data may be used for small files. Charges may apply.
   - **Wi-Fi only:** Never use mobile data to share.
   - **Without internet:** Files will always be shared offline.

# Connecting to Your Computer via USB

You can connect your phone to a computer with a USB Type-C cable to transfer files in both directions, charge the phone, or install software to update or repair the phone.

## Connect Your Phone to a Computer via USB

1. Connect your phone to the PC with a USB Type-C cable.
2. On the window opened, touch **ALLOW** to transfer files, **DENY** to charge the phone, or **Other USB options** to choose one of the following options:
   - **File Transfer:** Transfer files between the phone and the computer.
   - **PTP:** Transfer photos or files if MTP (File Transfer) mode is not supported by the computer.
   - **Charge this device:** Charge your phone via USB.
   - **System Update:** Install Software Upgrade Assistant on your computer and update or repair the phone.

## Disconnect Your Phone From the Computer

To disconnect the phone from the computer, simply unplug the USB Type-C cable when you're finished.

# Using the microSDXC Card as Portable or Device Storage

You can use your microSDXC card as portable storage for various files (such as music and photos). You can also set up a new microSDXC card or reformat an existing one to use as extra phone storage.

**CAUTION:**

As extra phone storage, the microSDXC card cannot work with other devices until it is reformatted and it may contain data necessary for some apps to function normally. Therefore, do not remove or replace the card randomly.

## Set Up the microSDXC Card as Portable Storage

When you install a new microSDXC card, the phone will mount it as portable storage by default.

***To remove the microSDXC card from your phone:***

If you need to remove the microSDXC card as portable storage while the phone is on, you must unmount it first.

1. Swipe up on the home screen and touch **Settings** > **Storage**.
2. Touch ⏏ next to the microSDXC card name in the Portable storage section.
3. When the screen shows that the card is safely ejected, you can pop out the card tray and remove the card from the phone.

***To erase and format the microSDXC card:***

1. Swipe up on the home screen and touch **Settings > Storage**.
2. Touch the microSDXC card name in the Portable storage section.
3. Touch **Format > FORMAT SD CARD**.
4. Touch **Done** when formatting is finished.

**CAUTION:**

The formatting procedure erases all data on the microSDXC card, after which the files CANNOT be retrieved.

## Set Up the microSDXC Card as Device Storage

If you need your microSDXC card to store large applications, games, and their data, you can format the card and use it as extra phone storage.

**CAUTION:**

With this option, you cannot swap the microSDXC card freely with other devices. If you move the card to another device, you must format the card before using it.

1. Swipe up on the home screen and touch **Settings > Storage**.
2. Touch the microSDXC card name in the Portable storage section.
3. Touch **Format as internal > FORMAT SD CARD**.

   **CAUTION:**

   The formatting procedure erases all the data on the microSDXC card, after which the files CANNOT be retrieved.
4. The phone will prompt you to move your photos, files and other data from the phone to the microSDXC card. Select **Move**

**content** or **Move content later**. Follow the on-screen instructions to continue.

5. Touch **Done**.

***To move data between the phone and the microSDXC card:***

With the microSDXC card as part of the device storage, you can move your photos, files and other data between the phone and the card any time.

1. Swipe up on the home screen and touch **Settings** > **Storage**.
2. To move data from the phone to the microSDXC card, touch the microSDXC card name; to move data from the card to the phone, touch **Internal shared storage**.
3. Touch ⋮ > **Migrate data** > **Move content**.
4. After data is moved, touch **Done**.

**NOTE:**

Whenever you move data between the phone and the microSDXC card, the destination is used to save new apps and personal data (such as photos and videos) and only the destination is accessible from a computer.

***To remove the microSDXC card from your phone:***

If you need to remove the microSDXC card as device storage while the phone is on, you must unmount it first.

1. Swipe up on the home screen and touch **Settings** > **Storage**.
2. Touch your microSDXC card name below **DEVICE STORAGE**.
3. Touch ⋮ > **Eject**.

**NOTE:**

Before ejecting the card, ensure that you have moved data and apps to the phone.

4. Touch **EJECT**.
5. When the screen shows the card is safely ejected, you can remove it from the phone.

***To reformat the microSDXC card as portable storage:***

If you no longer want to use your microSDXC card as extra device storage, you can reformat the card as portable storage.

**NOTE:**

Before the formatting, ensure that you have moved data and apps to the phone.

1. Swipe up on the home screen and touch **Settings** > **Storage**.
2. Touch your microSDXC card name below **DEVICE STORAGE**.
3. Touch ⋮ > **Format as portable** > **FORMAT**.
4. Touch **Done**.

**CAUTION:**

The formatting procedure erases all the data on the microSDXC card, after which the files CANNOT be retrieved.

# Sharing Mobile Data Through Tethering

You can share your phone's data capabilities through tethering, if your computer can obtain an Internet connection via USB cable or *Bluetooth*.

**NOTE:**

You cannot transfer files between your phone and your computer when the phone is USB tethered.

1. Swipe up on the home screen and touch **Settings** > **Network & internet** > **Hotspot & tethering**.
2. Touch **USB tethering** or **Bluetooth tethering**.
   - For USB tethering, connect your phone to the target device with the supplied USB cable before touching **USB tethering**.
   - For Bluetooth tethering, pair your phone with the other device via *Bluetooth* and set the device to obtain data connection via *Bluetooth*.

**NOTE:**

To stop sharing your data connection, switch off **USB tethering** or **Bluetooth tethering**.

# Phone Calls

You can place calls from the Phone app, the Contacts app, or other apps or widgets that display contact information. If you see a phone number, you can usually touch it to dial.

## Placing and Ending Voice Calls

### Place a Voice Call by Dialing

1. From the home screen, touch > .
2. Enter the phone number or the contact name with the dialpad. Touch to delete incorrect digits.

   **NOTE:**

   As you enter the phone number or the contact name, your phone searches for matching information in your contacts and call history. If you see the number and contact you want to call, touch it to place the call immediately.
3. Touch below the keypad to dial the call.

**NOTES:**

- To make an international call, touch and hold the **0** key to enter the plus (+) symbol. Next, enter the country code followed by the city/area code and then the phone number.
- To redial the last call you made, touch when the phone number field of the dialpad is empty to re-enter the number. Then touch again.

## End a Call

During a call, touch on the screen.

# Answering or Rejecting Voice Calls

When you receive a voice call, the incoming call screen opens, displaying the Caller ID or the information about the caller that you've entered in the Contacts app. You can answer or reject the call, or reject it with a text message.

## Answer a Voice Call

To answer an incoming call:

- If the phone screen is active, touch **ANSWER**.
- If the phone screen is locked, swipe up on the screen to answer the call.

**NOTES:**

- To silence the ringer before answering the call, press the **Volume** key or the **Power** key.
- For instructions on answering a call with RTT, see *Answer a RTT Call*.

## Reject a Voice Call

To reject an incoming voice call:

- If the phone screen is active, touch **DECLINE** to reject the call, or touch **MESSAGE** to reject the call and send a message to the caller.

- If the phone screen is locked, swipe down on the screen to reject the call, or swipe away from to reject the call and send a message to the caller.

**NOTE:**

To edit the preset text responses, open the **Phone** app and touch > **Settings** > **Quick responses**.

# Using Real-Time Text (RTT)

Your phone supports Real-Time Text. If you or person on the other end of the line has a hearing or speech impairment, you can use RTT on top of a voice call for a real-time conversation.

**NOTES:**

- You can use RTT only when the phone is connected to the 4G LTE network or a Wi-Fi network (with Wi-Fi calling enabled).
- Some RTT features and settings may not be supported under or across different networks.

## Set Up RTT Work Mode

1. From the home screen, touch > > **Settings** > **Accessibility** > **Real-time text (RTT) call**.
2. Touch **RTT operation mode** and choose one of the following to set when RTT options should be available:
   - **Visible during calls:** In this mode, calls will be placed and answered as voice-only calls by default unless you receive an incoming RTT call. You can still switch from voice-only to RTT during the calls. See *Switch From Voice-only Calls to RTT Calls*.

- **Always visible:** In this mode, you may select the mode for outgoing calls.

3. When RTT operation mode is set as **Always visible**, touch **RTT on Outgoing Call** to set the default mode for outgoing calls. You can choose to place all outgoing calls as RTT calls automatically (as long as the network is available) or choose manually each time before placing the call.

## Place a RTT Call

When the RTT operation mode is set as **Always visible**, you can place a RTT call directly.

1. Enter the phone number with the dialpad as usual.
2. Touch .
3. If RTT on Outgoing Call is set as **Manual**, touch **RTT Voice call**.

When the call is connected, the RTT message screen and keyboard appear automatically.

## Answer a RTT Call

Regardless of your RTT operation mode settings, an incoming RTT call is answered as a RTT call, with the RTT message screen and keyboard appearing automatically.

If the RTT operation mode is set as **Always visible**, you can choose to answer incoming voice-only calls as RTT calls by touching **RTT ANSWER** (when the screen is unlocked) or swiping from (when the screen is locked) at the bottom right.

**NOTE:**

Some features may not work under or across different networks.

## Switch From Voice-only Calls to RTT Calls

During a voice-only call, touch to start a RTT conversation. The voice conversation will not be affected. The other party can also make the switch, and your phone will show the message screen and keyboard automatically.

# Working With the Call History

The call history is a list of all the calls you've placed, received, or missed. It provides a convenient way to redial a number, return a call, or add a number to your Contacts.

To open the call history, open the **Phone** app and touch **> Call history**.

## Place a Call From the Call History

1. Open the call history.
2. Touch a number for more options about the call, or touch / beside it to call back.

**NOTE:**

You can touch **MISSED**, **INCOMING**, or **OUTGOING** to filter the records by call type.

## Save a Call History Number to a Contact

1. Open the call history.
2. Touch the number.
3. To add the number to an existing contact, touch **Add to a contact** and select a contact in the list. To add a new contact, touch **Create new contact**.
4. Edit the contact information if necessary, and touch **SAVE**.

## Retrieve RTT Call Transcript

1. Open the call history.
2. Touch a number that you had a RTT call with.
3. Touch **Call details**.
4. In the call list, touch to check the transcript during that call.

## Take Other Actions on a Call History Entry

1. Open the call history.
2. Touch a number and then touch an option. You can:
   - Touch **Create new contact** to save the number to a new contact.
   - Touch **Add to a contact** to save the number to an existing contact.
   - Touch **Send a message** to write a message to the number.
   - Touch **Block number** > **BLOCK** and you will no longer receive calls or messages from the number.

- Touch **Call details** to get more options, including:
  - **Copy number:** Copy the number to the clipboard.
  - **Edit number before call:** Edit the number in the dialer before calling it.
  - **Delete:** Delete the call history with this number.

**NOTE:**

You can touch > **Clear call history** in the Call history screen to delete all history records.

# Calling Your Contacts

1. From the home screen, touch .
2. Touch **Favorites** or **Contacts** to find your favorite contact or all your contacts.
3. Touch a contact in the **Favorites** tab, or touch / beside a contact in the **Contacts** tab.

# Checking Voicemail

If you have set the phone to divert calls to voicemail, callers can leave voicemail messages when they cannot reach you. Here's how to check the messages they left.

1. From the home screen, touch > .
2. Touch and hold the **1** key in the dialer. If prompted, enter your voicemail password.

3. Follow the voice prompts to listen to and manage your voicemail messages.

**NOTE:**

See *Set Voicemail* for how to set your voicemail service. For detailed information, please contact the service provider.

# Using Options During a Call

During a call, you will see a number of on-screen options. Touch an option to select it.

- Touch (or during a RTT call, touch > **Add call**) to make another call separately from the first call, which is put on hold.
- Touch to switch to the keypad when you need to enter a code (for example, the PIN for your voicemail or bank account) during the call.
- Touch to go to Contacts.
- Touch to mute or unmute your microphone.
- Touch to turn the speakerphone on or off.

  **WARNING!**

  Because of higher volume levels, do not place the phone near your ear during speakerphone use.

- Touch **Swap** or > **Swap** or the held call near the top of the screen to put the caller you are speaking to on hold, and switch to the other call that has been put on hold.
- Touch to merge the separate calls into a conference call.

- Touch to end the current call.
- Touch to switch from voice-only calls to RTT calls.

  **NOTE:**

  RTT only works on 4G LTE network.
- During a RTT call, touch > **Hide RTT keyboard** to close the RTT conversation and keyboard. You can then touch to restore the RTT conversation and keyboard.
- During a RTT call, touch > **DTMF keypad** to use the keypad to interact with automated systems with DTMF tones. You can touch **Hide** to return to your RTT messages.

# Managing Multi-party Calls

When the call waiting and the conference call features are available, you can switch between two calls or set up a conference call.

**NOTES:**

- Options and interface will vary. The call waiting and the conference call features need network support and may result in additional charges. Please contact your service provider for more information.
- Conference call is not available when you have an ongoing RTT call.

## Switch Between Current Calls

When you're on a call, you can place/answer a second call without ending the first one.

***To place the second call:***

Once you have established the first call, touch and dial the second number.

***To answer the second call:***

When you're on a call and another call comes in:

- Swipe up to answer the call. (This puts the first call on hold and answers the second call.)
- Swipe from to answer the call. (This ends the first call and answers the second call.)
- Swipe down to reject the second call.
- Swipe from to reject the second call and select a preset text message or write one to send to the caller.

***To switch between two calls:***

If the second call is an incoming call, touch > **Swap** or the held call near the top of the screen.

## Set Up a Conference Call

With this feature, you can talk to two people at the same time.

1. Place the first call.
2. Once you have established the connection, touch and dial the second number.

3. When you're connected to the second party, touch .

To end the conference call, touch .

**NOTE:**

If one of the people you called hangs up during your call, you and the remaining caller stay connected. If you initiated the call and are the first to hang up, all callers are disconnected.

# Adjusting Your Call Settings

You can configure a number of settings for the Phone application.

**NOTE:**

Some call options are displayed only when these features are available, and some features require network support and may result in additional charges. Please contact your service provider for more information.

## Set Contact Display Options

You can set the order of the contacts displayed in the **Contacts** tab of the Phone app.

1. From the home screen, touch > > **Settings** > **Display options**.
2. Touch **Sort by** or **Name format** to set the order of the contacts and the format of the contact names.

## Set Sound and Vibration

Set the sound and vibration for incoming calls as well as dialpad sounds.

1. From the home screen, touch > > **Settings** > **Sounds and vibration**.
2. Touch the option you want to configure.
   - Touch **Phone ringtone** to select the ringtone for incoming call notification.
   - Touch **Also vibrate for calls** to enable/disable vibration for incoming call notification.
   - Touch **Keypad tones** to play/mute sounds when you touch the dialpad keys.

## Set Options for Answering and Ending Calls

When enabled, the options allow you to end a call by pressing the **Power** key or make the phone vibrate when a call is answered.

1. From the home screen, touch > > **Settings** > **Answer and end calls**.
2. Touch **Power button ends call** or **Vibrate when call is answered**.

## Set Speed Dials

You can touch and hold the 1~9 keys from the dialer to call the corresponding speed dial number.

The number 1 key is reserved to speed dial your voicemail.

***To assign a speed dial key:***

1. From the home screen, touch > > **Settings** > **Speed dial**.
2. Touch a speed dial entry.
3. Touch a contact from the contact list.

## Edit Quick Response to Rejected Callers

1. From the home screen, touch > > **Settings** > **Quick responses**.
2. Touch a text message to edit it.
3. Touch **OK** to save the message.

## Set Wi-Fi Calling

When Wi-Fi calling is turned on and you are connected to a Wi-Fi network with Internet access, you can make and receive phone calls via Wi-Fi. This feature needs network support.

1. From the home screen, touch > > **Settings** > **Call settings** > **Wi-Fi calling**.
2. Touch the **Wi-Fi Calling** switch to enable/disable this feature. When Wi-Fi calling is enabled, touch **Update Current Emergency Address** to set the address for emergency (E911) call responders.

## Forward Incoming Calls

The call forwarding feature allows you to forward your incoming calls to another phone number.

1. From the home screen, touch > > **Settings** > **Call**

**settings > Call forwarding**.

2. Touch an available option to enable or disable it.

## Block Certain Numbers

The call blocking feature allows you to forbid calls and messages from certain numbers.

1. From the home screen, touch > > **Settings** > **Blocked numbers**.
2. Switch on **Unknown** to block calls from all unidentified callers.

   – or –

   To block calls and messages from specific numbers, touch **Add a number** and enter a phone number or touch to select one from the contact list. Then touch **Block**.

**NOTE:**

To unblock a number, touch next to the number and touch **Unblock**.

## Set Voicemail

1. From the home screen, touch > > **Settings**.
2. Touch **Voicemail** to configure voicemail settings.
   - Touch **Visual voicemail** to activate or turn off visual voicemail.
   - Touch **Change PIN** when visual voicemail is enabled to change the PIN for accessing your voicemail.
   - Touch **Advanced Settings** to select the voicemail service provider or view or change the voicemail number.

## Set Real-Time Text (RTT) Options

When you are connected to the 4G LTE network or a Wi-Fi network (with Wi-Fi calling enabled), from the home screen, touch > > **Settings > Accessibility > Real-time text (RTT) call** to set RTT options. For details, see *Set Up RTT Work Mode*.

## Set Hearing Aids

Your phone supports Hearing Aid Compatibility (HAC) function. When you turn on the hearing aid compatibility and use a hearing aid with a telecoil to answer the phone, it will help you hear more clearly during the phone call.

1. From the home screen, touch > > **Settings > Accessibility**.
2. Touch **Hearing aids** to turn on/off hearing aid compatibility.

**CAUTION:**

Do not turn on the Hearing aids option unless you use a hearing aid with a telecoil. Using this setting without a hearing aid or with a hearing aid without a telecoil may be harmful to your hearing.

# Contacts

You can add contacts on your phone and synchronize them with the contacts in your Google account or other accounts that support contact syncing.

To see your contacts, touch on the home screen.

## Checking Contact Details

1. From the home screen, touch .
2. Scroll through the list to view all your contacts.
3. Touch a contact to view its details.

## Adding a New Contact

1. From the home screen, touch .
2. Touch to add a new contact.
3. Enter the contact name, phone numbers, and email addresses. Touch **More fields** to enter other information. If you have multiple account types associated with your phone, touch **Saving to** and select an account. If a sync account is selected, the contacts can be synced automatically with the account online.
4. Touch **SAVE** to save the contact.

# Importing, Exporting, and Sharing Contacts

You can import/export contacts from/to the phone storage or a microSDXC card. This is especially useful when you need to transfer contacts between different devices. You can also quickly share your contacts using *Bluetooth*, Email, Gmail, Google Drive, or Messages.

## Import Contacts From the microSDXC Card or Phone Storage

1. From the home screen, touch .
2. Touch > **Settings** > **Import** > **.vcf file**.
3. If prompted, select the account the contacts will be imported to.
4. Navigate to the folder where the file is and touch the file.

## Export Contacts to the microSDXC Card or Phone Storage

1. From the home screen, touch .
2. Touch > **Settings** > **Export** > **Export to .vcf file**.
3. The phone will prompt you with the name of the vCard file. You can change the default name or touch to change the directory that the file will be saved to.
4. Touch **SAVE** to create the file.

## Share Contacts

1. From the home screen, touch .
2. Touch > **Settings** > **Export** > **Share all contacts**.
3. Open the notification panel and touch **Finished exporting contacts**.
4. Choose how to share the contacts. The options available depend on the applications and services installed.

**NOTE:**

To share a few selected contacts, touch and hold one in the contact list and then touch the other ones you need. After the selection, touch and choose how to share them.

# Working With Favorite Contacts

You can mark contacts as favorite to put them at the top of the contact list.

## Add a Contact to Favorites

1. From the home screen, touch .
2. Touch a contact and then touch at the top of the screen.

## Remove a Contact From Favorites

1. From the home screen, touch .
2. Touch a favorite contact and then touch .

# Managing Contacts With Labels

## View Your Contact Labels

1. From the home screen, touch .
2. Touch  to view existing contact labels in the Labels section.
3. Touch a label to view contacts with that label.

**NOTE:**

To send a message or an email to all contacts with the label, touch the label and touch  > **Send message / Send email**. Or touch the label and touch  > **Multi-select**, check the contacts you need, and touch  > **Send message / Send email**.

## Set Up a New Label

1. From the home screen, touch .
2. Touch  > **Create label**.
3. If prompted, select the account for the new label.
4. Enter the label name and touch **OK**.
5. Touch **ADD CONTACTS** or  and select the contact you wish to add the label to. To add multiple contacts, touch and hold one contact to select it. Then touch the other contacts and touch **ADD**.

## Delete a Label

1. From the home screen, touch .
2. Touch and then touch a label.
3. Touch > **Delete label**.
4. Touch **OK**. The contacts themselves will not be deleted.

## Edit a Label

1. From the home screen, touch .
2. Touch and then touch a label.
3. Touch > **Remove contacts** or **Rename label**.
4. Touch to remove the corresponding contact from the label, or edit the label name and touch **OK**.

# Managing Emergency Contacts and Information

You can set up your In Case of Emergency (ICE) contacts and your medical information for medical personnel to access even when the phone is locked.

## Add Emergency Contacts

You can add up to five contacts as emergency contacts.

1. From the home screen, touch **> In Case of Emergency contacts**.
2. Touch and, from the contact list, touch the contact you wish to be an emergency contact. To add multiple contacts, touch and hold one contact to select it. Then touch the other contacts and touch **ADD**.

   - or -

   Touch **> New contact** to create a new contact and set it as an emergency contact.

## Remove Emergency Contacts

1. From the home screen, touch **> In Case of Emergency contacts**.
2. Touch **> Remove contacts**.
3. Touch to remove the corresponding contact from the emergency contacts list.
4. Touch the **Back** key.

## Edit Emergency Information

1. From the home screen, touch **> In Case of Emergency contacts > My Emergency Information**.
2. Enter your name, health record, allergies, current medications,

and other information that you think hospital personnel need to know in the corresponding fields.

3. Touch ✓.

# Searching for a Contact

1. From the home screen, touch .
2. Touch to search.
3. Enter the contact name or other information (such as phone number) you want to search for. The contacts matched will be listed.

# Editing Contacts

## Edit Contact Details

1. From the home screen, touch .
2. Touch a contact and then touch .
3. Edit the contact and touch **SAVE**.

## Set a Ringtone for a Contact

Assign a special ringtone to a contact, so you know who is calling when you hear the ringtone.

1. From the home screen, touch .
2. Touch a contact you want to set a ringtone for, and then touch

> **More fields** > **Default ringtone**.

3. Select a ringtone you like and touch **OK**.
4. Touch **SAVE**.

**NOTE:**

When selecting ringtones, touch **Add ringtone** to select an audio file in your phone or microSDXC card.

## Delete Contacts

1. From the home screen, touch .
2. Touch and hold the contact you want to remove.
3. Check more contacts if needed, and then touch > **OK**.

## Link Contacts

If there are duplicate entries for the same person in your contacts, you can merge all the separate information of a contact into one entry in the Contacts list.

1. From the home screen, touch .
2. Touch and hold a contact to select it.
3. Touch to select the duplicate contact(s).
4. Touch > **Link**.
5. Touch **LINK** to confirm. All selected contacts are merged into one entry in the contacts list.

# Separate Contact Information

If contact information was linked in error, you can separate the information back into individual contacts on your phone.

1. From the home screen, touch .
2. Touch a linked contact you want to separate.
3. Touch **> View linked contacts > UNLINK**.
4. Touch **UNLINK** to confirm.

# Web Accounts

## Adding or Removing Accounts

You can add multiple Google accounts, Microsoft Exchange ActiveSync® accounts, and other kinds of accounts, depending on the apps installed on your phone.

### Add an Account

1. Swipe up on the home screen and touch **Settings > Accounts > Add account**.
2. Touch the type of account you want to add.
3. Follow the on-screen steps to enter the information about the account. Most accounts require a username and password, but the details may vary. You may also need to obtain some information from IT support or your system administrator.

When the account is successfully added, it is displayed in the Accounts menu in Settings.

### Remove an Account

Removing an account will delete it and all information associated with it, such as emails and contacts, from your phone.

1. Swipe up on the home screen and touch **Settings > Accounts**.
2. Touch the account you'd like to remove.
3. Touch **REMOVE ACCOUNT > REMOVE ACCOUNT**.

# Configuring Account Sync

## Configure Auto Sync Setting

1. Swipe up on the home screen and touch **Settings** > **Accounts**.
2. Touch **Automatically sync app data** to enable or disable automatic sync.
3. Touch **OK**.
   - When automatic sync is turned on, changes you make to information on your phone or on the web are automatically synced with each other.
   - When automatic sync is turned off, you need to sync manually to collect emails, updates, or other recent information.

## Sync Manually

1. Swipe up on the home screen and touch **Settings** > **Accounts**.
2. Touch the account you want to sync.
3. Touch **Account sync** > ⋮ > **Sync now**.

## Change an Account's Sync Settings

1. Swipe up on the home screen and touch **Settings** > **Accounts**.
2. Touch the account.
3. Touch **Account sync**. The Account sync screen appears, showing a list of information the account can sync.
4. When auto sync data is enabled, switch items on or off as you need. The enabled types of information will be kept in sync automatically between the phone and the web. When auto sync data is disabled, touch a listing to sync that type of information between the phone and the web.

# Email

Swipe up on the home screen and touch **Email**. Use it to read and send emails from Microsoft Exchange ActiveSync, Gmail, Yahoo!®, and more.

## Setting Up the First Email Account

1. When you open **Email** for the first time, touch an email server and then enter your email address and password.
2. Touch **NEXT** to let the phone retrieve the network parameters automatically.

   **NOTE:**

   You can also enter these details manually by touching **MANUAL SETUP** or if automatic setup fails.
3. Follow the on-screen instructions to finish the setup.

Your phone will show the inbox of the email account and start to download email messages.

## Checking Your Emails

Your phone can automatically check for new emails at the interval you set when setting up the account. You can also check new emails manually by dragging down on the message list. Touch **LOAD MORE** at the bottom of the email list to download earlier messages.

You can adjust how often your account downloads new emails. From your inbox, touch > **Settings** > name of the account > **Sync settings** > **Sync frequency**. Touch an option to select it.

# Responding to an Email

You can reply to or forward an email that you receive. You can also delete emails and manage them in other ways.

## Reply to or Forward an Email

1. Open the email you want to reply to or forward from the Inbox.
2. Choose one of the following:
   - To reply to the sender, touch .
   - To reply to the sender and all recipients of the original message, touch .
   - To forward the email to someone else, touch .
3. Edit your message and touch .

## Mark an Email as Unread

You can return a read email to the unread state—for example, to remind yourself to read it again later. You can also mark a batch of emails as unread.

- While reading a message, touch > **Mark unread**.
- While in a message list (for instance, the inbox), touch the sender icon on the left and then touch .

## Delete an Email

You can delete an email from its folder. You can also delete a batch of emails.

- While reading a message, touch .
- While in a message list (for instance, the Inbox), touch the sender icon on the left and then touch .

**NOTE:**

If you accidentally delete an email, touch **UNDO** to retrieve it.

# Writing and Sending an Email

1. Open your email Inbox and touch .

   **NOTE:**

   If you have more than one email account added on the phone, touch the From field to select the account you want to use for sending the message.

2. Enter a contact name or email address in the To field. Enter a comma, a semi-colon, or a space to separate each recipient. You can also touch **+** to select recipients from your contacts or history.

   **NOTE:**

   To send a carbon copy or blind carbon copy to other recipients, touch beside the To field to open the Cc/Bcc fields and enter the contact names or email addresses.

3. Enter the email subject and compose the email text.
4. Touch to add audio files, images, videos, and other types of files as attachments.
5. Touch near the top right of the screen to send the message.

# Managing Email Accounts

## Add an Email Account

After setting up your first email account (see *Setting Up the First Email Account*), you can add more email accounts and manage them separately.

1. Open the Email app.
2. Touch > **Settings** > **Add account**.
3. Set up the account as you did with the first one.

## Edit an Email Account

You can change a number of settings for an account. The options you can configure depend on the type of account.

1. Open the Email app.
2. Touch > **Settings** and touch the account whose settings you want to change.
3. Make the changes you want and touch or the **Back** key when you finish.

## Remove an Email Account

1. Open the Email app.
2. Touch ☰ > **Settings** and touch the account you want to remove.
3. Touch **Remove account from this device** > **OK**.

# Changing General Email Settings

General settings apply to all email accounts you add.

1. Open the Email app.
2. Touch ☰ > **Settings** > **General settings**.
3. Make the changes you want and touch ← or the **Back** key when you finish.

# Messages

You can use Messages to exchange text messages (SMS), multimedia messages (MMS), and chat messages.

## Opening the Messages Screen

Touch on the home screen.

The Messages screen opens, where you can create a new message, search for messages, or open an existing conversation.

- Touch **Start chat** to write a new message.
- Touch to search for a message using keywords.
- Touch an existing conversation to open the exchanged messages.

## Sending a Message

1. On the Messages screen, touch **Start chat**.
2. Add recipients in one of the following ways.
   - ▶ Manually enter the recipient's number or the contact name. If the phone presents a few suggestions, touch the one you want to add.
   - ▶ Touch a contact listed below the To field.
   - ▶ To add more recipients for an MMS group conversation, touch to add more recipients and then touch **Next**. Then touch **Skip** or edit the group name and touch **Next**.

3. Touch the Text message field and enter the message text. Touch to add emoji to your text message.
4. If you want to send a multimedia message, touch to add GIFs, stickers, location, contacts, or files to the message. To add pictures or videos to the multimedia message, touch and select existing files or shoot new photos/videos. To record an audio clip, touch and hold .

   **NOTE:**

   To capture a new photo, touch to switch between the front and the back cameras and touch to take a picture. To record a video, touch **> Video >** to start, and touch **> Attach** to stop and add the video to the message.
5. Touch and hold to add a message subject to your MMS or mark it as urgent.
6. Touch to send the message.

**NOTES:**

- If you add two or more people as recipients, the message may be sent as a group MMS where everyone can reply and see each other's messages. For group message setting, touch > **Settings > Advanced > Group messaging** from the Messages screen.
- You can also include email addresses as recipients for multimedia messages.
- Do not add any attachment if you want to send a text message. Otherwise, you may be charged for a multimedia message.

# Replying to a Message

Messages you receive are appended to existing conversations of the same number. If the new message comes from a new number, a new conversation is created.

1. On the Messages screen, touch the conversation that has the message you want to reply to.
2. Type your reply in the text field at the bottom. You can touch ⊕ or 🖼 or touch and hold 🎤 if you want to reply with an MMS.
3. Touch ▷.

# Forwarding a Message

1. On the Messages screen, touch the conversation that has the message(s) you want to forward.
2. Touch and hold one message you want to forward, and then touch ⋮ > **Forward**.
3. Touch the conversation you'd like to forward the message(s) to, or touch **New message** to enter new recipient(s).
4. Edit the message if necessary and touch ▷.

# Deleting Messages or Conversations

## Delete a Message in a Conversation

1. On the Messages screen, touch a conversation.
2. Touch and hold the message you want to delete.
3. Touch > **Delete**.

## Delete Message Conversations

1. On the Messages screen, touch and hold the conversation you want to delete.
2. If there are more conversations you want to delete, touch them one by one.
3. Touch > **Delete**.

# Web Browser

Use Chrome to view web pages and search for information.

## Opening the Browser

Touch on the home screen to launch the web browser. The browser also opens when you touch a web link—for example, in an email or a text message.

1. Touch the address box at the top.
2. Enter the address (URL) of a web page or terms you want to search for.
3. Touch a URL or search suggestion or touch the enter key on the keyboard to open the web page or search results.

**NOTE:**

Touch the **Back** key or ⋮ > → to go to the previous or the next web page.

## Using Multiple Browser Tabs

You can open several web pages at the same time (one page in each tab) and switch between them freely.

### Open a New Browser Tab

Touch ⋮ > **New tab / New incognito tab**. A new browser window opens.

## Switch Between Browser Tabs

1. Touch the 2 icon. The number in the icon indicates the number of currently active browser windows. Opened web pages will be listed. Swipe up and down to see them all.
2. Touch a thumbnail to switch to that tab.

**NOTE:**

Swipe a thumbnail horizontally or touch ⊗ to close the tab.

# Downloading Files

1. Touch and hold an image or a link to a file or to another web page.
2. In the menu that opens, touch **Download image** or **Download link**.

The downloaded files are saved to your phone or the microSDXC card. You can touch ⋮ **> Downloads** to view or open them.

# Camera

You can take photos and record videos. Photos and videos are stored on the microSDXC card, if you have installed one, or to the phone's internal storage. You can copy them to your computer or access them in the Photos app.

## Capturing a Photo

1. Touch on the home screen.
2. Aim the camera at the subject and make any necessary adjustment. PHOTO (auto camera) mode is used by default.
3. Touch the area where you want the camera to focus, or leave the camera to autofocus on the center of the image.

| Number | Function |
|---|---|
| 1 | Change the flash setting. |
| 2 | Change the camera settings. |
| 3 | Turn on/off HDR or set it at auto. |
| 4 | View pictures and videos you have taken. |
| 5 | Capture a photo. |
| 6 | Switch between the front and back cameras. |

| | |
|---|---|
| 7 | Switch among the default PHOTO mode, VIDEO mode, PORTRAIT mode, WIDE mode, BOKEH mode, and more. |
| 8 | Use auto-beauty mode or customize the personal options to beautify faces in the picture. |
| 9 | Select a filter. |

4. Lightly touch ◯ to take the picture.

**WARNING!**

Keep a safe distance when using the flash. Do not point the flash toward the eyes of people or animals.

**NOTES:**

- You can pinch or spread your fingers on the screen to zoom in or zoom out before taking a picture (only useable in PHOTO, MANUAL, and SELFIE mode).
- In PHOTO (auto camera) mode, when you touch the screen to focus, the exposure icon appears beside the focus box. You can drag the icon up or down to adjust the exposure.

# Recording a Video

1. From the home screen, touch > **VIDEO**.
2. Aim the camera at the subject.
3. Touch to start recording. You can also touch or to pause or resume recording, or touch to save the frame as a photo.

4. Touch to stop recording.

**NOTES:**

- You can pinch or spread your fingers on the screen to zoom in or zoom out before and during recording (not useable in wide-angle view).
- When you touch the screen to focus during recording, you can touch and hold the focus box to lock the focus, or drag the exposure icon  beside the focus up or down to adjust the exposure.
- To capture a time-lapse video, touch **MORE > TIMELAPSE** below the preview area. Adjust the time interval. Then touch to begin recording and to stop. You can also touch to save the frame as a photo.

# Using Manual Camera Mode

You can use Manual camera mode to adjust more camera options for your photo.

1. From the home screen, touch **> MORE > MANUAL**.
2. Aim the camera at the subject. You can make the following adjustments.
   - ▶ Drag the yellow circle to any area on the screen where you want the camera to meter exposure so as to adjust the photo brightness. Touch and hold the circle to lock exposure.
   - ▶ Drag the blue square to any area on the screen that you want

to focus on. Touch and hold it to lock or unlock the focus.

- Touch the icons near the bottom of the preview area and drag the sliders to adjust ISO, exposure, white balance, and interval for taking consecutive shots.

3. Touch ◯ to take the photo.

## Using Portrait Mode

You can use Portrait mode to focus on your subject with a depth effect and blurred backgrounds.

1. From the home screen, touch **> PORTRAIT**.
2. Aim the camera at the subject and you can make the following adjustments.
   - viewfinder screen to select one for your photo.
   - Touch to enable auto AI framing and follow the on-screen instructions to help the camera focus on the subject.
   - Touch to enable the auto-beauty feature.
3. Touch ◯ to take the photo.

## Using Panorama Mode

You can use the panorama camera mode to capture horizontally or vertically elongated photos.

1. From the home screen, touch **> MORE > PANORAMA**.

2. Touch or to change the direction the photo should stretch out.
3. Touch and move the phone in the direction of the arrows on the screen. Take care to keep the arrows on the center line as you move.
4. Touch when you reach the end.

## Using Other Camera Modes

Your camera app offers other powerful camera modes.

- **BOKEH:** Take a photo with the subject in focus and the background blurred. You can adjust the slider to change the shutter aperture.

  **NOTE:**

  For a picture taken in BOKEH mode, you can open it in full screen in the Photos app, touch **> Bokeh Refocus**, and then touch anywhere on the picture to refocus or adjust the blurriness.

- **WIDE:** Capture wide-angle pictures.
- **TIMELAPSE:** Set the time interval between each frame when you shot time-lapse videos.

## Customizing Camera and Video Settings

Before capturing a photo or video, you can touch to open the following options.

**NOTE:**

Some camera and video options will change in different camera modes.

## Options in Photo Mode (Back Camera)

- **Resolution:** Set the resolution for your photo.
- **Timer:** Set a time delay before the camera takes a picture automatically after you touch the shutter icon.
- **Composition:** Show or hide the grid or golden spiral to help with balanced photo composition.
- **Gradienter:** Show or hide the gradienter.

## Options in Selfie Mode (Front Camera)

- **Resolution:** Set the resolution for your photo.
- **Timer:** Set a time delay before the camera takes a picture automatically after you touch the shutter icon.
- **Tap to capture:** When this feature is enabled, you can touch the viewfinder screen to take a photo.
- **Mirror image:** When enabled, allows you to capture a photo that is the same as the viewfinder preview.

## Options in Video Mode (Front or Back Camera) and Timelapse Mode

**Video quality:** Set the quality for your video.

## Options in Portrait Mode and Bokeh Mode (Back Camera)

**Timer:** Set a time delay before the camera takes a picture automatically after you touch the shutter icon.

## Options in Wide Mode (Back Camera)

- **Timer:** Set a time delay before the camera takes a picture automatically after you touch the shutter icon.
- **Composition:** Show or hide the grid or golden spiral to help with balanced photo composition.
- **Gradienter:** Show or hide the gradienter.

## Options in Manual Mode (Back Camera)

- **Resolution:** Set the resolution for your photo.
- **Timer:** Set a time delay before the camera takes a picture automatically after you touch the shutter icon.
- **Metering:** Adjust the light metering setting.
- **Composition:** Show or hide the grid or golden spiral to help with balanced photo composition.
- **Gradienter:** Show or hide the gradienter.

## General Options

- **Add ZTE watermark automatically:** Add the phone name as a watermark on the photo (not available in video-recording modes, panorama mode, or manual mode).
- **Add date watermark automatically:** Add date as a watermark on the photo (not available in video-recording modes, panorama mode, or manual mode).
- **Shutter tone:** Turn the shutter tone on or off.
- **Geo-tagging:** When enabled, store the location data in your captured photos and videos.
- **Volume key:** Assign the function of the **Volume** key (available in photo-capturing modes).
- **Anti-banding:** Set the anti-banding value when you take pictures or videos of TV or computer screens to avoid stripes on the screen.
- **Save location:** Change the storage location for captured photos and videos.
- **Help icon in the view-finder:** Enable the Help icon on the viewfinder screen.
- **More help:** View Help details.
- **Restore defaults:** Restore default camera and video settings.

# FM Radio

With the FM radio, you can search and listen to FM radio broadcast. Note that the quality of radio reception depends on the coverage of the radio stations in your area. A wired headset works as an antenna, so always connect a headset when using the FM radio.

## Scanning and Saving Channels

1. Swipe up on the home screen and touch **FM Radio** while a wired headset is plugged in.
2. Touch ⋮ > **Scan**. Your phone scans for all available channels and saves them to the All channels list.

**NOTE:**

When you open the FM Radio app for the first time, it will automatically scan for channels and show the All channels list. You can also touch ⋮ > **All channels** to view the list.

## Listening to FM Radio

1. Open FM Radio while the headset is connected.
2. Touch ⋮ > **All channels** and select a channel.

You can also drag the frequency panel or touch 〈 or 〉 to switch to other channels. Touch ⊖ or ⊕ to adjust the channel frequency.

**NOTES:**

- Touch ☆ to add the channel to Favorites, which are displayed at the bottom of the FM Radio screen.
- Touch to listen to the radio through the phone speaker.

## Other Options and Settings

**To set the FM frequency range:**

FM radio frequency ranges differ among regions. Touch ⋮ > **FM frequency range** and select a frequency range.

**To turn off FM radio automatically:**

Touch ⋮ > **Auto off** and set the time you want to turn off the FM radio.

A count-down clock appears above the frequency and the radio is turned off when the clock counts down to 0:00.

**To turn off FM radio immediately:**

Touch ⋮ > **Exit**.

# Voice Recorder

Voice Recorder enables you to record and listen to voice memos.

## Recording a Voice Memo

1. Swipe up on the home screen and touch **Voice Recorder**.
2. Touch to select the audio format of the recording.
3. Touch to start recording. During recording, you can:
   - Touch or to pause or continue the recording.
   - Touch or to add an empty tag or photo tag to the recording.

   **NOTE:**

   If ringtone and notification sounds are enabled before the recording, they will be temporarily turned off during it to avoid interference. Your phone will still vibrate for calls and notifications.
4. Touch **DONE** to stop recording.
5. Edit the file name and touch **SAVE** to save the recording.

If you don't want to save the memo after recording it, touch **DELETE** > **DELETE** to delete it.

# Playing a Voice Memo

1. Touch at the top right of the screen to see all recordings.
2. Touch the title of a memo to play it. During the playing, you can touch to change the play speed, or touch or to add an empty tag or photo tag.

**NOTE:**

Touch **View tag** to check all time tags. You can then touch "+" after an empty tag to add an image or text, touch an image to delete it or replace it with another image, or touch and hold a tag to delete it.

# Trimming a Voice Memo

1. While playing a recording, touch to open the editing screen.
2. Drag  or to trim the recording. You can touch to play the trimmed part.
3. Touch **TRIM**.
4. Edit the new file name and touch **SAVE**.

# More Apps

## Calculator

Swipe up on the home screen and touch **Calculator** to use the built-in calculator for some basic as well as advanced mathematical equations.

**NOTE:**

To see more calculator options, swipe left while holding the phone in portrait view or turn the phone to landscape view.

## Clock

Swipe up on the home screen and touch **Clock**. The Clock app allows you to check local time in places around the world, set alarms, and use timers and nightstand clock.

### Set a New Alarm

1. Open the Clock app and touch the tab.
2. Touch a default alarm to configure it, or touch at the bottom of the screen to create a new alarm.
3. Set up the alarm options, such as time, repeat, snooze, alarm ringtone, vibration, and label.
4. Touch **SAVE** to save and exit.

**NOTES:**

- To enable or disable existing alarms directly, touch the switches on the right side of each alarm.
- Touch ⋮ to set more alarm options in the Alarm section.

## Check World Time

1. Open the Clock app and touch the tab.
2. World time lets you check local times for cities around the world. Touch + to add a new city.

**NOTE:**

In addition to checking the current time from various places, you can change the time of your location and find out the corresponding time of other places. Touch your local time displayed above all other places and swipe up and down to change the hour and minute. As your local time changes, the time of other places changes accordingly.

## Using Stopwatch and Countdown

1. Open the Clock app and touch or .
2. Use the stopwatch to record lap times (up to 100 laps), or use the countdown timer feature to set a time and count down to zero.

## Configure the Clock App Settings

Open the clock app and touch ⋮ to access options for alarm and timer.

# File Manager

Quickly access all of your images, videos, audio clips, and other types of files on your phone and on the memory card.

Swipe up on the home screen and touch **File Manager**. Then touch a file type to find the file you need by category, or touch **Phone** or **SD card** to browse folders and files on the phone storage or the microSDXC card.

- Touch folders and files to open them.
- Touch and hold a folder or file or touch ⋮ > **Multi-Select** to access options such as copy, move, compress, share, rename, delete, add to Favorites, or add as a shortcut to the home screen.
- To copy or move an item, touch and hold the item, touch ⋮ > **Move** or **Copy**, navigate to a new location, and touch **PASTE**.
- Touch + to create a new folder in the current directory.
- Touch 🔍 to search for a file or folder by name.
- Touch ⋮ > **Sort by** to sort the contents in the current directory by file name, file size, file type, or modification time.
- Touch ⚙ in the root directory and switch on **Show local hidden files** to display hidden system files and folders.

# Weather

Swipe up on the home screen and touch **Weather** to get weather forecast.

By default, only the weather forecast of your current location is displayed. Swipe down to update the weather data. You can also touch ☰ > + to add more cities or touch ☰ > ✎ to remove cities or change their order.

**NOTE:**

The weather of the city at the top of the list is displayed in the Weather widget on the home screen.

# Google Apps

**NOTE:**

Google services may not be available in certain region.

- **Calendar:** Keep track of life's important events with Google Calendar synced across your devices.
- **Chrome:** Browse the Internet and get your bookmarks, browsing history, and more synced with your Google account.
- **Drive:** Store files on Google servers for free after you sign in to your Google account. You can access them on your computers, your phones, and other devices, share them, or collaborate with others.
- **Duo:** Video chat one-on-one using Wi-Fi or mobile data.

- **Find Device:** Use Find My Device to locate, lock, or wipe your lost device remotely. The lost device must be signed in to a Google account.
- **Gmail:** Send and receive emails via your Gmail account or other personal email accounts.
- **Google:** Use Google search or get information when you need it with the Google Assistant.
- **Maps:** Find points of interest such as restaurants and local businesses. You can also get directions for various modes of transportation.
- **News:** Get comprehensive up-to-date news coverage, aggregated from sources all over the world by Google News.
- **Photos:** Manage photos on the phone and your Google account.
- **Play Movies & TV:** Buy or rent movies and TV programs from the Play Store.
- **Play Store:** Purchase and download apps, games, and more from the Google Play store.
- **YouTube:** Watch video clips from YouTube.com, or upload your own and share with the world.
- **YT Music:** Play and browse songs and playlists on your phone or from your YouTube Music account.

# Settings

Swipe up on the home screen and touch **Settings**. Settings contains most of the tools for customizing and configuring your phone. In some menus, you may need to touch **Advanced** to see all the options.

At the top of the Settings screen, you can see setting suggestions. Touch to check or customize the recommended settings.

# Network & Internet

## Wi-Fi

Open **Settings** and touch **Network & internet > Wi-Fi** to turn Wi-Fi on or off and configure your Wi-Fi connections (see *Connecting to Wi-Fi*).

## Mobile Network

Open **Settings** and touch **Network & internet > Mobile network** to control mobile data use, data roaming, preferred network type and operator, data usage, and access point names (see *Connecting to Mobile Networks*).

## Airplane Mode

Open **Settings** and touch **Network & internet > Airplane mode** to turn airplane mode on or off. All the phone's radios (such as cellular, Wi-Fi, and *Bluetooth*) that transmit voice or data are turned

off when airplane mode is on.

## Hotspot & Tethering

Open **Settings** and touch **Network & internet > Hotspot & tethering** to share your phone's mobile data connection with PCs or other devices. See *Sharing Mobile Data Through Tethering*.

## Data Saver

Open **Settings** and touch **Network & internet > Data Saver** to enable Data saver, which prevents apps from using data connection in the background. For an app you're currently using, it can access data, but may do so less frequently when Data saver is enabled. You can also touch **Unrestricted data** and allow some apps to always have access to data connection even when Data saver is turned on.

## Call Settings

Open **Settings** and touch **Network & internet > Call settings** to configure Wi-Fi calling and call forwarding options. You can also access the options from the Phone app by touching ⋮ (next to **Search contacts**) **> Settings > Call settings**. See *Set Wi-Fi Calling* and *Forward Incoming Calls*.

## VPN

Open **Settings** and touch **Network & internet > VPN** to set up and connect to virtual private networks. Virtual private networks (VPNs) allow you to connect to the resources inside a secured local

network. VPNs are commonly deployed by corporations, schools, and other institutions to let people access local network resources when not on campus, or when connected to a wireless network. Depending on the type of VPN you are using, you may be required to enter your login credentials or install security certificates before you can connect to your VPN. You can get this information from your network administrator.

### Roaming State

Open **Settings** and touch **Network & internet** to check to roaming state of your phone in the **Roaming state** section.

### Wireless Emergency Alerts

Open **Settings** and touch **Network & internet > Wireless Emergency Alerts** to manage options for receiving emergency alert messages.

### Private DNS

Open **Settings** and touch **Network & internet > Private DNS** to turn Private DNS on or off or change the DNS provider hostname. Using private DNS is a way to secure your Internet communication.

## Connected Devices

Open **Settings** and touch **Connected devices** to manage your phone's connection via *Bluetooth*, USB, and to wireless printers, screens, automobiles, and Chromebooks. You can touch **Pair new**

**device** to pair new *Bluetooth* devices or touch **Connection preferences** to configure *Bluetooth* settings (See *Connecting to Bluetooth Devices*), wireless display, printer services, Chromebook connections, Android Auto, and Nearby Share (See *Sharing Files With Nearby Devices*).

When your phone is connected to a computer via USB, you can touch **Connected devices > USB** to manage the USB connection mode (see *Connecting to Your Computer via USB*).

# Apps & Notifications

## App Info

Open **Settings** and touch **Apps & notifications** to see recently opened apps. Touch **SEE ALL [number] APPS** to see all apps installed on your phone and manage them.

Touch an app to see its information and configure the available options.

## Conversations

Open **Settings** and touch **Apps & notifications > Conversations** to check your priority and modified conversations in the Messages app and change conversation settings. Once you mark a conversation as priority by touching and holding it on the notification panel, or make any other changes to a conversation, it will appear in this menu.

## Notifications

Open **Settings** and touch **Apps & notifications** > **Notifications** to manage app notifications.

## Screen Time

Open **Settings** and touch **Apps & notifications** > **Screen time** to find out how much time you spend on the phone and set daily time limits for most apps. When you reach the time limits, apps are closed and their icons dim for the rest of the day so that you can disconnect.

## Default Apps

Open **Settings** and touch **Apps & notifications** > **Default apps** to select the default app for voice assistant and input, web browsing, messaging, phone call and the home launcher. Touch **Opening links** to set Instant apps options, or touch an installed app to check its supported links, set whether to open the links in the app, and clear the app's defaults.

## Permission Manager

Open **Settings** and touch **Apps & notifications** > **Permission manager** to check and change app permissions to access certain data on the phone.

**WARNING!**

Changing app permissions may stop some apps from working correctly or as originally intended.

### Wireless Emergency Alerts

Open **Settings** and touch **Apps & notifications > Wireless emergency alerts** to manage options for receiving emergency alert messages.

### Special App Access

Open **Settings** and touch **Apps & notifications > Special app access** to set special access and authorizations of apps.

## Battery

Open **Settings** and touch **Battery** to view the battery level, check what has been using the battery, and optimize battery use.

## Features

Open **Settings** and touch **Features**. The following features are available.

- **System navigation:** Change the navigation bar style.

  **NOTE:**

  Check how to use each navigation style in this menu's HELP section.

- **Record screen:** Set the video quality and the touch interaction options for screen recording.

**NOTE:**

To record the screen and save it as a video, swipe down the status bar with two fingers and touch **Record screen** in the Quick Settings panel. Touch or to mute or unmute the audio for the recording. Then touch to start recording and or to pause or stop.

- **Gesture & motion:** You can control the phone with special finger gestures or by moving the phone in different ways. Touch the switches to enable each function; touch each function to view how to use it or try it out.
- **One-handed mode:** Enable or disable one-handed mode when virtual navigation is in use. See *Using One-Handed Mode*.
- **Scheduled power On/Off:** Set the day and time when the phone automatically powers on or off. Touch the switches on the right to turn the features on or off.

# Display

Open **Settings** and touch **Display** to configure the display options, including brightness level, Night Light mode, Dark theme, wallpaper, screen timeout, screen rotation, font size, and more.

# Sound

Open **Settings** and touch **Sound** to adjust different types of volume (see *Adjusting Volumes*), set notification mode (see *Switching to Silent or Vibration Mode*), set Do not disturb options

(see *Using Do Not Disturb Mode*), set up ringtones (see *Changing the Ringtone or Notification Sound*), or control system sounds (see *Turning System Sounds On/Off*).

# Storage

Open **Settings** and touch **Storage** to check memory information for your microSDXC card and phone storage.

- **Saving location:** Touch **Phone** or **SD card** to select the default location for new data, such as recorded voice memos.
- **DEVICE STORAGE:** Touch **Internal shared storage** to get detailed breakdown of space usage by type. Touch **MANAGE STORAGE** to remove files and apps you do not need or turn on **Storage manager** to remove backed up photos and videos automatically after certain time.
- **PORTABLE STORAGE:** Safely mount, unmount (remove), and format your microSDXC card. For more information about using the microSDXC card as portable storage or device storage, see *Using the microSDXC Card as Portable or Device Storage*.

# Privacy

Open **Settings** and touch **Privacy** to manage app permissions (see *Permission Manager*), password display, lock screen notifications, and information shared with Google (such as autofill data, location history, ad ID, and activities.)

# Location

Open **Settings** and touch **Location** to manage location services to help your phone and apps determine your location. To use location-related apps, such as finding your location on Google Maps, you must have location services turned on.

You can also check the apps that recently requested your location data, manage location permission for each app, turn on/off Wi-Fi and Bluetooth scanning, and control other location-related services.

# Security

Open **Settings** and touch **Security** to configure options that help keep your phone and data safe.

- **Google Play Protect:** Allow Google to regularly check your apps and phone for harmful behavior and warn you about any detected potential harm. Touch and switch on **Scan apps with Play Protect** to enable this feature. To send unknown apps to Google for better detection, touch and switch on **Improve harmful app detection**.
- **Find My Device:** Locate, lock, or wipe your lost device remotely. You must sign in to your Google account to use this feature.
- **Security update:** Check for system updates and install them when they become available. You can also view update history or use Software Upgrade Assistant installed on your computer to install updates to the phone via a USB cable (see *Connecting to Your Computer via USB*).

- **Screen lock:** Secure your phone and personal data with a screen lock (see *Protecting Your Phone With a Screen Lock*).

  After you set a pattern, PIN, or password as the screen lock, touch beside **Screen lock** to set the following options.

  - **Make pattern visible:** Show the pattern as you draw it. This option is available when a pattern screen lock is set.
  - **Lock after screen timeout:** Set the time needed for the lock protection to be activated after the screen turns off.
  - **Power button instantly locks:** Lock protection is activated immediately when you press the **Power** key.
- **Fingerprint:** Register up to 5 fingerprints for unlocking the phone. See *Using Your Fingerprint*.
- **Face recognition:** Use face recognition to unlock the screen. See *Using Face Recognition*.
- **Smart Lock:** Keep the phone unlocked when connected to trusted devices, in trusted places, or while being held or carried.

  **NOTE:**

  You need to sign in to your Google account on the phone to use all the Smart Lock features.
- **Device admin apps:** Activate or deactivate apps to be device administrators.
- **SIM card lock:**
  - **Lock SIM card:** Activate or deactivate the PIN lock to require PIN before accessing the nano-SIM card.

- **Change SIM PIN:** Change the PIN used to access the nano-SIM card.

  **NOTE:**

  Put all your confidential passwords in a safe place for future use. If you enter the wrong SIM PIN more times than allowed, your nano-SIM card will be locked and you cannot access the mobile network. Contact your operator for a PIN Unlock Key (PUK) to restore the nano-SIM card.

- **Encryption & credentials:** Check the encryption status of your phone and set the credential storage options.
- **Trust agents:** Activate or deactivate trust agents.
- **App pinning:** Pin an app's screen to keep it in view until you unpin it. This feature can be used, for example, to let a trusted friend play a specific game (see *Protecting Your Phone With App Pinning*).

# Accounts

Open **Settings** and touch **Accounts** to manage your accounts and synchronization (see *Web Accounts*.)

# Accessibility

Open **Settings** and touch **Accessibility** to configure accessibility plug-ins and services on your phone, such as using **Color inversion** or **Font size** for users with sight problems.

# Digital Wellbeing & Parental Controls

Open **Settings** and touch **Digital Wellbeing & parental controls** to get information about how you spend time on your phone, like how often you unlock it and how long you use each app. You can use that information to improve your digital wellbeing. You can also help your child balance their screen time with the Family Link app.

- Touch **Show your data** to get information on how you spend time on your phone and apps.
  - **Dashboard:** Check the screen time, number of notifications, and opened times of each app. You can set daily timers for the most-used apps to avoid indulgence (see *Screen Time*.)
  - **Bedtime mode:** Set a bedtime schedule to disconnect and avoid interruptions while you sleep.
  - **Focus mode:** Select distracting apps and turn on focus mode to pause these apps when you need time to focus.
  - **REDUCE INTERRUPTIONS:** Manage app notifications and Do Not Disturb settings to reduce interruptions from your important tasks.
  - **Show icon in the app list:** Display or hide the Digital Wellbeing app in the app list.
- In the Parental controls section, touch **Set up parental controls** to add content restrictions and set other limits for your child with the Family Link app.

# Google

Open **Settings** and touch **Google** to manage settings for your Google account and Google services.

# System

## Languages & Input

Open **Settings** and touch **System > Languages & input** to configure options related to system language, input methods, speech input and output as well as mouse/trackpad pointer.

- **Languages:** Select a language for your system (see *Changing the System Language*.)
- **On-screen keyboard:** Configure on-screen keyboard input methods and Google voice typing.
- **Physical keyboard:** Configure assistive options for physical keyboards connected to your phone.
- **Spell checker:** Use Google spell checker to check for spelling errors when entering text and change its settings.
- **Autofill service:** Enable or disable autofill service and choose the service provider. To use Google Autofill, you need to sign in to your Google account.
- **Personal dictionary:** Add new words to the phone's dictionary or remove words from the dictionary. The words you add are used for spell check and word suggestion.

- **Pointer speed:** Select how fast the pointer/mouse should scroll when you connect the phone to a trackpad or mouse accessory.
- **Text-to-speech output:** Select the speech synthesis engine or change its settings, select the output language, set speech rate and pitch, and play a brief sample of the speech synthesizer.

## Date & Time

Open **Settings** and touch **System > Date & time** to set date, time, time zone, and how time is displayed. You can also use network-provided data (see *Setting the Date and Time*).

## Downloads

Open **Settings** and touch **System > Downloads** to check files you have downloaded.

Touch a file to open it; press and hold for multi-selection for sharing and deletion.

## Backup

Open **Settings** and touch **System > Backup** to back up your phone data to your Google Drive, so you can easily restore or switch phones at any time. Backup includes apps and app data, call history, contacts, device settings, and messages.

## Reset Options

Open **Settings** and touch **System > Reset options** to reset network settings, app preferences, system settings, or the phone to

factory default status.

## Multiple Users

Open **Settings** and touch **System > Multiple users** to manage the user accounts of your phone.

Turn on the switch at the top to use the multiple users feature. You can share your phone with other people by creating additional users. Each user has his/her own apps, wallpaper, screen lock and so on.

Touch **Add guest > Switch to Guest** to create a guest account for anyone who needs to use your phone temporarily. You can touch **Add user** to create more user accounts.

If you want users to add more users when the phone is locked, switch on **Add users from lock screen**. Anyone can then open the Quick Settings panel from the lock screen and touch > **Add user** to create new users or profiles.

**NOTE:**

When a guest user has finished using your phone, he/she can touch **Remove guest** in the **Multiple users** menu to delete all his/her data from your phone.

# About Phone

Open **Settings** and touch **About phone** to view important hardware and software information of the phone, SIM status, regulatory ID, and legal information.

# System Updates

Open **Settings** and touch **System updates** to check for system updates and install them when they become available. You can also view update history, use Smart Updates to install security updates automatically, or use Software Upgrade Assistant installed on your computer to install updates to the phone via a USB cable (see *Connecting to Your Computer via USB*).

# Upgrading the Phone Software

There are several ways to upgrade your phone software.

- Use the online upgrade tool for mobile terminal products.
- Use the one-press upgrade package offered by your mobile service provider.
- Use your PC to download and upgrade package to your microSDXC card and install it to your phone from the card.

**NOTE:**

Visit the ZTE official handset service support website **Z-Community** (https://community.zteusa.com) to learn more about the above upgrade methods, as well as which phones and methods are supported.

# Troubleshooting

If you encounter problems while using the phone, or if it performs abnormally, you can refer to the chart below. If your particular problem cannot be resolved using the information in the chart, contact the dealer where you purchased the phone.

| Problem | Possible Causes | Possible Solution |
|---|---|---|
| Poor reception | The network signal is too weak at your current location (for example, in a basement or near a tall building) because wireless transmissions cannot effectively reach it. | Move to a location where the network signal can be properly received. |
| | The network is busy at the current time (for example, during peak times, there may be too much network traffic to handle additional calls). | Avoid using the phone at such times, or try again after waiting a short time. |
| | You are too far away from a base station for your service provider. | You can request a service area map from your service provider. |

| Problem | Possible Causes | Possible Solution |
|---|---|---|
| Echo or noise | Poor network link quality on the part of your service provider. | End the call and dial again. You may be switched to a better-quality network link or phone line. |
| | Poor local telephone line quality. | End the call and dial again. You may be switched to a better-quality network link or phone line. |
| Unable to select certain features | Your service provider does not support these features, or you have not applied for services that provide these features. | Contact your service provider. |
| Cannot charge the battery | The battery or battery charger is damaged. | Contact the dealer. |
| | The phone's temperature is below 32°F (0°C) or higher than 95°F (35°C). | Adjust the battery charging environment to avoid extremes of temperature. |
| | Poor contact between the battery and charger. | Check all connectors to ensure that all connections have been properly made. |

| Problem | Possible Causes | Possible Solution |
|---|---|---|
| Shortened standby time | The standby time is related to your service provider system configuration. The same phone used with different service providers' systems will not provide exactly the same length of standby time. | If you are located in an area where signaling is weak, temporarily power off the phone. |
| | The battery is depleted. In high temperature environments, battery life will be shortened. | Contact the dealer to change a new battery. |
| | If you are not able to connect to the network, the phone will continue to send out signals as it attempts to locate a base station. Doing so consumes battery power and will consequently shorten standby time. | Change your location to one where the network is accessible, or temporarily turn off your phone. |
| Cannot turn your phone on | Battery power has been depleted. | Recharge the phone's battery. |

| Problem | Possible Causes | Possible Solution |
|---|---|---|
| nano-SIM card error | The nano-SIM card has malfunctioned or is damaged. | Take the nano-SIM card to your service provider for testing. |
| | The nano-SIM card is inserted improperly. | Insert the nano-SIM card properly. |
| | Debris is on the nano-SIM card contacts. | Use a soft, dry cloth to clean the nano-SIM card contacts. |
| Unable to connect to the network | The nano-SIM card is invalid. | Contact your service provider. |
| | You are not within the network's service area. | Check the service area with your service provider. |
| | Poor signal. | Move to an open space, or if you are inside a building, move closer to a window. |
| Cannot answer incoming calls | You have activated the Call blocking feature. | Disable this feature. Open the Phone app and touch ⋮ > **Settings** > **Blocked numbers**. Touch ✕ > **Unblock** next to the number you want to unblock. |

| Problem | Possible Causes | Possible Solution |
|---|---|---|
| PIN Code blocked | You have entered an incorrect PIN code three consecutive times. | Contact your service provider. If the service provider provides the nano-SIM card's PUK code, use the PUK code to unlock the nano-SIM card. |
| Phone crashes, reboots, freeze, or cannot be powered on | Some third-party software is not compatible with your phone. | Uninstall the software that may cause the problem. |
| | | Upgrade the phone software. |
| | | Reset the phone to factory status. |

# For Your Safety

## General Safety

| | |
|---|---|
| | Don’t make or receive phone calls while driving. Never text while driving. |
| | Keep your phone at least 10 mm (0.4 inches) away from your body while making calls. |
| | Small parts may cause choking. |
| | Your phone can produce a loud sound. |
| | To prevent possible hearing damage, do not listen at high volume levels for long periods. Exercise caution when holding your phone near your ear while the loudspeaker is in use. |
| | Avoid contact with anything magnetic. |
| | Keep away from pacemakers and other electronic medical devices. |
| | Turn off when asked to in hospitals and medical facilities. |
| | Turn off when told to on aircraft and at airports. |

| | |
|---|---|
| | Turn off when near explosive materials or liquids. |
| | Don’t use at gas stations. |
| | Your phone may produce a bright or flashing light. |
| | Don’t dispose of your phone in fire. |
| | Avoid extreme temperatures. |
| | Avoid contact with liquids. Keep your phone dry. |
| | Do not attempt to disassemble your phone. |
| | Only use approved accessories. |
| | Don’t rely on your phone as a primary device for emergency communications. |

# Radio Frequency (RF) Energy

This phone is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the United States.

During SAR testing, this device was set to transmit at its highest

certified power level in all tested frequency bands, and placed in positions that simulate RF exposure in usage against the head with no separation, and near the body with the separation of 0.4 inches (10 mm). Although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

The exposure standard for wireless devices employing a unit of measurement is known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg.

This device is complied with SAR for general population/uncontrolled exposure limits in ANSI/IEEE C95.1-1992 and had been tested in accordance with the measurement methods and procedures specified in IEEE1528.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of **www.fcc.gov/oet/ea/fccid** after searching on **FCC ID: SRQ-Z6251V**.

For this device, the highest reported SAR value for usage against the head is **1.38 W/kg**, and for usage near the body is **1.15 W/kg**.

While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirements.

SAR compliance for body-worn operation is based on a separation distance of 0.4 inches (10 mm) between the unit and the human body. Carry this device at least 0.4 inches (10 mm) away from your body to ensure RF exposure level compliant or lower to the reported level. To support body-worn operation, choose the belt clips or holsters, which do not contain metallic components, to maintain a separation of 0.4 inches (10 mm) between this device and your body.

RF exposure compliance with any body-worn accessory that contains metal was not tested and certified, and use of such body-worn accessory should be avoided.

# FCC Regulations

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to

radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**CAUTION:**

Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

The antenna(s) used for this transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

## Hearing Aid Compatibility (HAC) Regulations for Mobile Phones

In 2003, the FCC adopted rules to make digital wireless telephones compatible with hearing aids and cochlear implants. Although analog wireless phones do not usually cause interference with hearing aids or cochlear implants, digital wireless phones sometimes do because of electromagnetic energy emitted by the phone's antenna, backlight, or other components. Your phone is

compliant with FCC HAC regulations (ANSI C63.19- 2011).

While some wireless phones are used near some hearing devices (hearing aids and cochlear implants), users may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than others to this interference noise and phones also vary in the amount of interference they generate. The wireless telephone industry has developed a rating system for wireless phones to assist hearing device users in finding phones that may be compatible with their hearing devices. Not all phones have been rated. Phones that are rated have the rating on their box or a label located on the box. These ratings are not guaranteed. Results will vary, depending on the level of immunity of your hearing device and the degree of your hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated phone successfully. Trying out the phone with your hearing device is the best way to evaluate it for your personal needs.

This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer wireless technologies used in this phone that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Consult your service provider or the manufacturer of this phone for information on hearing aid compatibility. If you have questions about return or exchange policies, consult your service provider or phone retailer.

**M-Ratings:** Phones rated M3 or M4 meet FCC requirements and are likely to generate less interference to hearing devices than phones that are not labeled. M4 is the better/higher of the two ratings.

**T-Ratings:** Phones rated T3 or T4 meet FCC requirements and are likely to be more usable with a hearing device's telecoil ("T Switch" or "Telephone Switch") than unrated phones. T4 is the better/higher of the two ratings. (Note that not all hearing devices contain telecoils.)

Your phone has been tested for hearing aid device compatibility and has an **M4/T4** rating.

Hearing devices may also be measured for immunity to this type of interference. Your hearing device manufacturer or hearing health professional may help you find results for your hearing device.

For additional information about the FCC's actions with regard to hearing aid compatible wireless devices and other steps the FCC has taken to ensure that individuals with disabilities have access to telecommunications services, please go to www.fcc.gov/cgb/dro.

# Distractions

## Driving

Full attention must be given to driving at all times in order to reduce the risk of an accident. Using a phone while driving (even with a hands-free kit) can cause distraction and lead to an accident. You must comply with local laws and regulations restricting the use of wireless devices while driving.

## Operating Machinery

Full attention must be given to operating the machinery in order to reduce the risk of an accident.

# Product Handling

## General Statement on Handling and Use

You alone are responsible for how you use your phone and any consequences of its use.

You must always switch off your phone wherever the use of a phone is prohibited. Use of your phone is subject to safety measures designed to protect users and their environment.

- Always treat your phone and its accessories with care and keep them in a clean place.
- Keep the screen and camera lens clean. An unclean screen or camera lens may slow down the phone's reaction to your operations or interfere with the image quality.
- Clean your phone and its accessories with a soft material such as cleaning cloth for eyeglass lenses. Do not use alcohol or other corrosive substances for cleaning or allow them to get inside.
- Do not expose your phone or its accessories to open flames or lit tobacco products.

- Do not expose your phone or its accessories to liquid, moisture or high humidity.
- Do not drop, throw or try to bend your phone or its accessories.
- Do not use harsh chemicals, cleaning solvents, or aerosols to clean the device or its accessories.
- Do not paint your phone or its accessories.
- Do not attempt to disassemble your phone or its accessories. Only authorized personnel can do so.
- Do not place your phone inside or near heating equipment or high-pressure containers, such as water heaters, microwave ovens, or hot cooking utensils. Otherwise, your phone may be damaged.
- Please check local regulations for disposal of electronic products.
- Do not carry your phone in your back pocket as it could break when you sit down.

## Battery Safety

- Using ZTE-unapproved or incompatible battery, charger or power adapter may damage your device, shorten its lifespan or cause a fire, explosion or other hazards.
- The recommended operating temperatures are 0 °C to 35 °C and the storage temperatures are -20 °C to +45 °C. Extreme temperatures can damage the device and reduce the charging capacity and lifespan of your device and battery.

- Do not remove the back cover. The battery is not removable. Removal may cause fire or explosion.
- Do not change or replace the built-in rechargeable battery in your device by yourself. The battery can only be changed or replaced by ZTE or ZTE-authorized service provider.
- Do not place the device or the battery in or near heating equipment, such as microwave ovens, stoves or radiators. Keep the device and the battery away from excessive heat and direct sunlight. If not, the device or the battery may overheat and cause explosion or fire.
- Do not disassemble, squeeze or puncture the device, as this can cause explosion or fire.
- Do not throw the device into a fire to avoid explosion.
- Please disconnect the charger when the battery is fully charged. Overcharging may shorten the battery life.
- When not using the device for a long period, please charge the battery about half and then store the device in a cool dry place.
- If the battery damages or shows signs of swelling or leakage, please stop use immediately and contact ZTE or a ZTE-authorized service provider for replacement.

## Small Children

Do not leave your phone and its accessories within the reach of small children or allow them to play with it. They could hurt themselves or others, or could accidentally damage the phone.

Your phone contains small parts with sharp edges that may cause an injury or may become detached and create a choking hazard.

## Demagnetization

To avoid the risk of demagnetization, do not allow electronic devices or magnetic media close to your phone for a long time.

## Electrostatic Discharge (ESD)

Do not touch the metal connectors on the nano-SIM card and the microSDXC card.

## Antenna

Do not touch the antenna unnecessarily.

## Normal Use Position

When placing or receiving a phone call, hold your phone to your ear, with the bottom towards your mouth.

## Airbags

Do not place a phone in the area over an airbag or in the airbag deployment area, as an airbag inflates with great force and serious injury could result. Store the phone in a safe and secure area before driving your vehicle.

## Seizures/Blackouts

The phone can produce a bright or flashing light. A small percentage of people may be susceptible to blackouts or seizures (even if they have never had one before) when exposed to flashing lights or light patterns such as when playing games or watching video. If you have experienced seizures or blackouts or have a family history of such occurrences, please consult a physician. To reduce the risk of blackouts or seizures, use your phone in a well-lit room and take frequent breaks.

## Repetitive Strain Injuries

To minimize the risk of Repetitive Strain Injury (RSI) when texting or playing games with your phone:

- Do not grip the phone too tightly.
- Press the buttons lightly.
- Use the special features which are designed to minimize the times of pressing buttons, such as Message Templates and Predictive Text.
- Take frequent breaks to stretch and relax.

## Emergency Calls

This phone, like any other wireless phone, operates using radio signals, which cannot guarantee connection in all conditions. Therefore, you must never rely solely on any wireless phone for emergency communications.

## Loud Noise

This phone is capable of producing loud noises, which may damage your hearing. Turn down the volume before using headphones, *Bluetooth* headsets or other audio devices.

## Phone Heating

Your phone may become warm during charging and during normal use.

# Electrical Safety

## Accessories

Use only approved accessories. Do not connect with incompatible products or accessories. Take care not to touch or allow metal objects, such as coins or key rings, to contact or short-circuit the charging port. Never puncture the surface of the phone with sharp objects.

## Connection to Vehicles

Seek professional advice when connecting a phone interface to the vehicle electrical system.

## Faulty and Damaged Products

Do not attempt to disassemble the phone or its accessories. Only qualified personnel can service or repair the phone or its accessories. If your phone (or its accessories) has been submerged

in water, punctured, or subjected to a severe fall, do not use it until you have taken it to be checked at an authorized service center.

# Radio Frequency Interference

## General Statement on Interference

Care must be taken when using your phone in close proximity to personal medical devices, such as pacemakers and hearing aids. Please consult your doctor and the device manufacturers to determine if the operation of your phone may interfere with the operation of your medical devices.

## Pacemakers

Pacemaker manufacturers recommend that a minimum separation of 6 inches (15 cm) be maintained between a mobile phone and a pacemaker to avoid potential interference with the pacemaker. To achieve this, use the phone on the opposite ear to your pacemaker and do not carry it in a breast pocket.

## Hearing Aids

People with hearing aids or other cochlear implants may experience interfering noises when using wireless devices or when one is nearby. The level of interference will depend on the type of hearing device and the distance from the interference source. Increasing the separation between them may reduce the interference. You may also consult your hearing aid manufacturer to discuss alternatives.

### Medical Equipment

Turn off your wireless device when you are requested to do so in hospitals, clinics or healthcare facilities. These requests are designed to prevent possible interference with sensitive medical equipment.

### Aircraft

Turn off your wireless device whenever you are instructed to do so by airport or airline staff. Consult the airline staff about the use of wireless devices onboard the aircraft and enable airplane mode of your phone when boarding an aircraft.

### Interference in Vehicles

Please note that because of possible interference with electronic equipment, some vehicle manufacturers forbid the use of mobile phones in their vehicles unless a hands-free kit with an external antenna is included in the installation.

## Explosive Environments

### Gas Stations and Explosive Atmospheres

In locations with potentially explosive atmospheres, obey all posted signs to turn off wireless devices such as your phone or other radio equipment. Areas with potentially explosive atmospheres include fueling areas, below decks on boats, fuel or chemical transfer or storage facilities, and areas where the air

contains chemicals or particles, such as grain, dust, or metal powders.

## Blasting Caps and Areas

Power off your mobile phone or wireless device when in a blasting area or in areas where signs are posted to power off "two-way radios" or "electronic devices" to avoid interfering with blasting operations.